

OEM TM-50 Taping Module with Dual Jam Sensors User's Guide

User's Guide # D292414D

V-TEK, Inc.
751 Summit Avenue
Mankato, MN 56001
(P) 507-387-2039
www.vtekusa.com



EC Declaration of Conformity

Manufacturers Name: V-TEK Inc.
Manufacturers' Address: 751 Summit Avenue
Mankato, MN 56001 USA

Declare that the machinery described below complies with applicable health and safety requirements of Part 1 of Annex 1 of the Machinery Directive 2006/42/EC and EMC Directive 2004/108/EC. Confidential technical documentation has been compiled in accordance with Part A of Annex VII of Machinery Directive 2006/42/EC and is available to European national authorities on written request only. If a request is received documentation will be delivered on a CD or by post.

Description: Taping & Inspection Machines.
Model Number: TM 50 Standard, XL, OEM, and I3.
Specification: For 8-72mm Width Tape, Up to 120mm for XL
Serial Number/s: 201XXXXXXX

The following standards have either been referred to or been complied with in part or in full as relevant:

EN ISO 12100:2010	Safety of machinery -	Safety of machinery - General principles for design - Risk assessment and risk reduction
EN ISO 13849-1:2008	Safety of machinery -	Safety Related Parts of Control Systems - Part 1 General Principles for Design
EN ISO 13732-1:2008	Safety of machinery -	Ergonomics of the thermal environment - Methods for the assessment of human responses to contact with surfaces
EN 614-1:2006+A1:2009	Safety of machinery -	Ergonomic design principles - Part 1: Terminology and general principles
EN 614-2:2000+A1:2008	Safety of machinery -	Ergonomic design principles - Part 2: Interactions between the design of machinery and work tasks
EN 953:1997+A1:2009	Machinery Safety -	General requirements for the design and construction of guards
EN 13850: 2008	Safety of machinery -	Emergency-stop equipment, Principles for Design
EN 60204-1:2010	Safety of machinery -	Electrical Equipment of Machines
EN ISO 11202/A1 1997	Acoustics -	Noise emitted by machinery and equipment - Determination of emission sound pressure levels at a work station and at other specified positions.
EN 61000-6-3:2007	EMC -	Generic standards - Emission standard for residential, commercial and light-industrial environments
EN 61000-6-1: 2007	EMC -	Generic standards - Immunity for residential, commercial and light-industrial environments

Full Name of responsible person and place of signing


Christina Hogan

Place V-TEK Inc.

Position Vice President

Signature

Date 01/03/2012



Preface

This User's Guide describes how to setup and operate the TM-50 Taping Machine. This manual should be read and thoroughly understood before operating the machine.

The TM-50 Taping Machine is built with the following standard features.

Features:

- Adjustable track assembly for tape widths 8mm to 56mm
- Independently controlled seal temperature for each side of the cover tape
- Dual stage fully adjustable Heat and PSA sealer assembly
- User-friendly software assures ease of setup and operation
- Sensor package including low cover tape sensor, carrier tape motion sensor, empty pocket sensor and jam-in-track sensor
- Software controlled advance movement of carrier tape (2mm to 24mm pitch)
- Current operating parameters and count are saved at power down and restored at power up

Options include:

- Low carrier tape and pocket position sensor
- Controller location
- Feed and take-up reel positions
- Loading track length
- Mounting options
- Machine footprint
- Customized software and communication

Theory of Operation

The OEM TM-50 routes carrier tape from a feed reel through an adjustable track for manual placement of parts or electrical components. Once the operator has filled all of the carrier tape pockets in the loading area with parts, a foot pedal is used to advance the tape to a sealer assembly.

If the OEM TM-50 was purchased with the optional *Extended Software Package*, a sensor detects jams in tape, empty pockets and low cover tape supply as the tape advances.

Once the carrier tape reaches the OEM TM-50 sealer assembly, a cover tape is applied. The part is then sealed in the pocket with either a Heat Seal or Pressure Sensitive Application (PSA). When the sealing process is complete, the finished tape is routed onto a take-up reel.

Machine Details

Operating Temperature

0 Degrees Celsius to + 60 Degrees Celsius

Although all of the components used on the machine will withstand the temperature range of 0 degrees Celsius to +60 degrees Celsius, such temperature may decrease the life of some of the components. The recommended rating is 0 degrees Celsius to +50 degrees Celsius.

Humidity

5% to 90% non-condensing

Physical Specifications

Dimensions

Height 18 inches (46 cm)

Width 42 inches (107 cm)

Depth 18 inches (46 cm)

Weight

105 pounds (47.63 kg)

Power Required

- 115/230 VAC, 50-60 Hz
- Compressed air, 80 PSI

Contact Information

V-TEK, Inc.

751 Summit Ave

Mankato, MN 56001

TEL: (507) 389-2039

website: <http://www.vtekusa.com>

For customer service, please refer to the Customer Service Contact Sheet at the back of this manual.

Intended Use

The intended use of the TM-50 Taping Machine is to produce taped reels of individually sealed and consistently orientated components. It is designed to accommodate a full range of electronic devices. Use of this equipment in any other way is not recommended.

Suitable carrier and sealing tapes include any conductive or non-conductive tapes with feed-holes that are pitched at 4 mm. Tapes must operate in a temperature range from 135-155° Celsius with a pressure range from 40-60 psi and dwell time between 250-400 milliseconds. The OEM TM-50 can accommodate tape widths from 8mm to 56mm.

Tape advance speed is set on the machine's controller and can be set at any speed from 5-250 random units. Feed rates can vary from 500 to 5000 units per hour dependent on component size of integrated input.

Operating Environment

The OEM TM-50 is designed to be operated in a temperature controlled, light, industrial setting. The machine should be installed on a flat, dry, stable surface in a well lit area (ambient lighting of 200 to 300 Lux (Lumens/m2).

The recommended climate is between 5 - 90% non-condensing humidity with a room temperature between 0 - 50 degrees Celsius.

Note: Although all of the components used on the machine will withstand the temperature range of 0 to 60 degrees Celsius, such temperature may decrease the life of some of the components.

The intended electrical environment is Pollution Degree 2 and Over Voltage Category II.

Misuse

The OEM TM-50 tape advance should not be activated when parts are being placed in tape, when tape reels are being loaded or replaced, or when jams in tape are being cleared. Although the torque on the Stepper Motor has been limited to reduce the risk of injury, advancing the tape during these tasks may result in pinching or entrapment of fingers.

The user is protected from moving parts and exposure to objects being ejected under pressure by metal enclosures. The OEM TM-50 should never be operated with these enclosures removed.

The user is protected from the OEM TM-50's heat sealer by a metal guards. Operators are cautioned not to touch the heat seal guard or to try to reach underneath the guard while the OEM TM-50 is in operation.

Safety Precautions

General Precautions

Only qualified personnel with the proper technical training, experience working on this type of equipment, and awareness of the possible hazards should perform maintenance on the TM-50.

The TM-50 should be installed on a level and stable surface before any operation or maintenance is performed.

This manual should be read and thoroughly understood before operating the machine. The guidelines provided in the following pages are intended to educate the user about how to operate the TM-50 safely. They contain important information on avoiding potential hazards to the operator and to the equipment.

Observe the following safety precautions when working with the TM-50.



Maintenance

Always disconnect the power source from the machine before removing access panels to perform any maintenance required. Please refer to Chapter 1 and Chapter 4 of this manual for instructions before performing maintenance on the machine.



AC Receptacle

Connect the power cord to the machine before plugging it into an outlet.



Heat Sealer

Caution should be taken when performing maintenance on the sealer. The body of the heat sealer can remain hot for several minutes after it has been shut off. Before servicing, turn the power switch to OFF, turn off the air supply to the machine, and allow the sealer to cool.



Connectors

Dangerous voltage is present. Make sure the machine is turned off and the power cord is disconnected before removing any panels. Do not remove the slide mount rear panel while the power is connected to the machine.



Idler Wheel

Use caution not to pinch fingers in the idler wheel.

Safety Warning Labels

Safety Warning Labels

The following warning labels have been placed in various places on the machine to bring safety issues to the attention of operators and technicians working with or near the machine. It is advised that these warning labels not be removed or obstructed.



Attention

Indicates an adjustment or danger zone requiring attention.



Electrical Hazards

Indicates that hazardous voltage levels are present. Always disconnect power to the machine before removing panels or enclosures with this warning label.



Temperature Hazards

Indicates a hot surface. Use care when working near these surfaces and allow them to cool before performing maintenance.



Mechanical Hazards

Indicates areas where moving parts can cause personal injury if safety precautions are not observed.



Open Book

Refer to Chapter 4 of this manual before performing maintenance on the TM-50.

Contact Information

V-TEK, Inc.
751 Summit Ave
Mankato, MN 56001
TEL: (507) 389-2039
website: <http://www.vtekusa.com>

For customer service, please refer to the Customer Service Contact Sheet at the back of this manual.

OEM TM-50

Table of Contents

EC Declaration of Conformity

Preface

Theory of Operation	i
Machine Details	ii
Intended Use	iii
Safety Precautions	iv
Safety Warning Labels	v
Contact Information	v

Chapter 1: Getting Started1

Preparing the Work Area	2
Unpacking the OEM TM-50	4
Assembling the OEM TM-50	5
Machine Overview	9

Chapter 2: Controller13

The TM-50 Controller	14
Extended Software Option	19
Using the Vision Port	23

Chapter 3: Setup and Operation.....29

Preparing to Run a Job	30
Quick Setup Guide	30
Preparing to Run a Job	31
Heat Seal Setup	36
PSA Seal Setup	39
Testing Seal Strength	40
Operation	41
Using the Empty Pocket Detector	43
Using E-Stop in Malfunction/Fail Situations	45

Chapter 4: Maintenance Instructions.....47

Safe Maintenance Steps	48
Maintenance Schedule	49
Maintenance Instructions	50
Electrical Connections	53

OEM TM-50

Table of Contents (continued)

Exploded Views

Appendix A - Sensors

Appendix B - Temperature Controller Settings

Spare Parts List

Service and Parts Contacts

Document List

Warranty Document


Chapter I: Getting Started

Contents

Preparing the Work Area	2
Unpacking the OEM TM-50	4
Assembling the OEM TM-50	5
Machine Overview	9

Preparing the Work Area

The OEM TM-50 is a table-top machine which needs to be mounted on a flat, stable surface in a well lit area that is a minimum of 6' high x 10' wide x 5'deep (2m x 3m x 1.5m). When positioning the OEM TM-50, choose an area that is not located below overhead gantries, walkways or power lines to ensure objects or liquids cannot be dropped on the machine from overhead.




The OEM TM-50 will also require access to a 85-110 PSI air pressure system and a 115/230 VAC, 50-60 Hz power supply. Locate the machine so electrical power cables can be routed away from areas where personnel are expected to move. It is recommended that cables be routed overhead or underground. If cables must be routed over the floor, cover them with rubber ramps.

Choose a mounting area that is at least 72" wide by 30" deep to provide sufficient space for the assembled machine when it is fully loaded with a variety of tape reel sizes.

The mounting surface should have a slope of no more than 5 degrees and be capable of supporting a load of 65 pounds (30 kg).

When loading, unloading or running the TM-50, the operator should stand in front of the machine controller to assure easy access to all controls and the **Power/Emergency Stop** button. This position also allows the operator to view all parts of the TM-50 while it is in operation.

Allow at least 24" clearance at the front and sides of the machine for easy access and operation. (Pictured in the overhead view below.)



Unpacking the OEM TM-50

The following items should be included in the shipping crate:




Figure 1.1

- | | |
|---------------------------------------|-------------------------|
| A. Cover Tape Reel Support Controller | E. Controller Baseplate |
| B. Take-up Motor Assembly | F. Air Regulator |
| C. Feed Reel Support | G. Tape Guide |
| D. Baseplate Assembly | H. Controller |

The following items are also included in the shipping crate but not pictured above:

- Power Cord
- Hex Wrenches
- Foot Switch
- Peripheral Cable
- BP OEM TM-50 User's Guide

Equipment Required

- Hex wrenches
- 80 PSI air pressure system

Assembling the OEM TM-50

Before the TM-50 is shipped from V-TEK, the machine is disassembled to prevent damage in transit. Follow these instructions to reassemble the machine::





Figure 1.2

1. Remove items one at a time from the crates and place on a flat, stable surface for assembly.

Note: The baseplate assembly weighs approximately 50 pounds (23 kg). Use two people to lift the base assembly from the crate and position it in the assembly area. See the illustration below for lift points.



2. Remove and discard protective wrapping from each part.

3. Using a 3/16" hex wrench, remove the (2) 1/4" SHCS located on the backside of the loading track near the *Heat Sealer*. Bolt the *Cover Tape Reel Support* to the *Track Support Bracket*.




Figure 1.3

4. There are (4) *Amplifiers* located on the back side of the loading track a short distance from the *Cover Tape Reel Support*. Lift the top of the *Amplifier* closest to the track to access the small grey switch inside. Push the switch up, then insert the double-pronged fiber optic cable from the *Cover Tape Reel Support Arm* into the matching opening on the *Amplifier*.



Figure 1.4

Switch

5. Attach the *Take-up Spindle* to the *Take-up Motor Assembly* by sliding it onto the pin and tightening the set screw with a 3/32" hex wrench.




Figure 1.5

6. Remove the black knob from the left side of the track support bracket. The *Take-up Support Arm* has a dowel pin which locks into position holes on the track support bracket. Slide the *Take-up Support Arm* onto the threaded rod, engage the dowel pin into the desired position, and secure it into place with the black knob. Plug the electrical connector into the *Take-up Motor Receptacle*.




Figure 1.6

7. Remove the black knob from the *Feed Reel Arm* which extends from the bottom of the *Base Assembly*. Slide the *Feed Reel Support Arm* onto the threaded rod, adjust it to the desired position, and then secure it into place with the black knob.





Figure 1.7

8. Remove the (4) 8-32 x $\frac{3}{4}$ " BHCS which attach the *Pulley Mounts* to the *Pulley Covers* (A).

Remove the (2) 8-32 x $\frac{3}{4}$ " BHCS from the top of the *Pulley Mounts* and insert them in the bottom of the *Pulley Mounts* (B). Use the BHCS to attach the *Pulley Mounts* to the right end of the *Loading Track* (C).

Attach the *Pulley Covers* to the *Pulley Mounts* pedestal using (4) 8-32 x $\frac{3}{4}$ " BHCS (A).



9. If the OEM TM-50 includes a *Pedestal* to mount the *TM-50 Controller*, attach the *Controller Baseplate* to the *Pedestal* using the provided screws.

Place the *Controller* on the *Controller Baseplate*. Engage the (4) corner holes in the *Controller Baseplate* with the (4) rubber feet on the bottom of the *Controller* so that it is seated securely.





Figure 1.9

10. Connect the *Peripheral Cable* to the right side of the machine and then to the receptacle labeled **PERIPHERAL** on the back of the *Controller*.




Figure 1.10

11. If a *Foot Switch* was included with the machine, plug it into the receptacle labeled **FOOT SWITCH** on the back of the *Controller*




Figure 1.11

12. Plug the *Power Supply Cord* into the receptacle labeled **POWER** on the back of the *Controller*.




Figure 1.12

13. Install the *Air Regulator* on the back of the *Sealer Controller* with the provided screws. Attach the blue air hose to the air fitting on the right side of the *Sealer Control Box*.




Figure 1.13

14. Connect a 1/4" airline to the *Air Regulator* and set the regulator to **80 psi**, if necessary. It can be adjusted by lifting the adjustment knob and turning it. Once it reads 80 psi, push the knob back in to lock it into place.

Note: An air supply is only necessary for the operation of the heat sealer. Suggested settings are between 80-110 psi.



Caution!

The fully assembled machine weighs 105 pounds (47 kg). If the machine needs to be moved to a different location, use two people to safely lift the machine.

Machine Overview

Before the OEM TM-50 is placed in operation, use the photos in the following section to perform a visual inspection and ensure that it is correctly assembled.

Left Side




Figure 1.14

- | | |
|----------------------------|--------------------|
| A. Take-up Motor | E. Rear Tape Guide |
| B. Take-up Reel Spindle | F. Drive Sprocket |
| C. Peripheral Connector | G. Idler Wheel |
| D. Take-up Motor Connector | |

Heat Sealer Controls



Figure 1.15

- | | |
|-------------------------------------|--------------------------------|
| A. Inside Seal Temperature Control | D. Heat Seal Pressure Adjuster |
| B. Heat Seal ON/OFF Switch | E. Inner Sealer Position Lock |
| C. Outside Seal Temperature Control | |

The Universal Sealer




Figure 1.16

- | | |
|---------------------------------|---------------------------------------|
| A. Outer Seal Position Lock | E. Cover Tape Guide Width Adjuster |
| B. Outer Seal Position Adjuster | F. Inner Seal Position Adjuster |
| C. PSA Seal Roller | G. Inner Seal Position Lock |
| D. Cover Tape Position Adjuster | H. PSA Seal Pressure Adjustment Screw |

Controller Front Side



Figure 1.17

- | | |
|----------------------------|---------------|
| A. Power/E-Stop Button | C. LCD Screen |
| B. Take-up Tension Control | D. Keypad |

Loading Track




Figure 1.18

- | | |
|--------------------------------|------------------------|
| A. Tape Jam Sensor 2 | E. Inner Loading Track |
| B. Empty Pocket Detector (EPD) | F. Outer Loading Track |
| C. Amplifiers | G. Carrier Tape Guides |
| D. Tape Jam Sensor 1 | |

Right Side




Figure 1.19

- | | |
|------------------|--------------------------|
| A. Take-up Motor | E. Feed Reel Support Arm |
| B. Take-up Arm | F. Sealer |
| C. Tape Guide | G. Carrier Tape Guides |
| D. Reel Lock | |

Amplifiers

- A. Tape Jam Sensor 2 Amplifier
- B. Tape Jam Sensor 1 Amplifier
- C. Empty Pocket Detector Amplifier
- D. Low Cover Tape Amplifier



Rear Track

Controller Back Panel





Figure 1.20

- A. Vision:** Connects the TM-50 to optional Vision Systems.
- B. Sensor Thru:** Allows external machines to monitor the TM-50's sensors.
- C. I/O:** Connects the TM-50 to optional auto-feed mechanisms.
- D. Peripheral:** Connects the TM-50 controller to the base machine.
- E. Foot Switch:** Connects the foot switch to the TM-50 controller.
- F. AC Power Receptacle:** Connects the TM-50 to external power supply.
- G. Comm Port:** Connects the TM-50 to optional external computer.

Serial Plate



Chapter 2: Controller

Contents

The TM-50 Controller	14
Extended Software Option	19
Using the Vision Port	23

The TM-50 Controller

The TM-50 Controller is used to set all the parameters of the TM-50's operation with the exception of the sealer temperature controls and the take-up tension control.



Figure 2.1

The controller uses a simple menu-driven program for changing the current settings and running the machine. This program is displayed on the LCD screen and navigation of the menus and data entry are performed using the keypad to the left of the LCD screen.



Figure 2.2

The microprocessor stores all settings and the current parts counter value in memory when the machine is powered down and restores them when it is powered up again.

Note: Power off the TM-50 Controller before inserting or removing any cables or cords from the ports on the back of the controller. Failure to power off the controller before making changes may result in damage to the controller and the external device.

Controller Operation

When the TM-50 is powered up, the controller will display an initial welcome screen shown in Figure 2.3.




Figure 2.3

From this screen, the operator can choose to begin running the machine immediately or to review and change the machine settings. As the screen indicates, pressing the LEFT ARROW key on the keypad will select the Setup Menu and pressing the RIGHT ARROW key will select Run Mode.

Setup Menu

The Setup Menu consists of eight menu options, seven of which are used to review and change an aspect of the TM-50's operation. These options include: count, pitch, tape advance, speed, sealer dwell, tape jog, and mode. The last option is used to enter Run Mode after setup is complete and the operator is ready to begin a run. The Menu will appear as shown in Figure 2.4.

1>COUNT	2>PITCH
3>ADVANCE	4>SPEED
5>DWELL	6>JOG
7>MODE	8>RUN

Figure 2.4

An option is selected by pressing the number key on the keypad that is indicated by the Setup Menu screen. Pressing the escape (ESC) key will exit and return to the Setup Menu. Data entry is performed by entering the desired number with the keypad and pressing the enter (ENT) key to enter it.

When a menu option is selected, a new screen will appear. These screens are described below.

Count

The count screen (Figure 2.5) is used to clear the current parts count value to 0 and to set the parts counter STOP value.

```
1>RESET count to 0
2>SET Stop value

REV 2.xx
```

Figure 2.5

To clear the parts count, press 1 while in this screen. The counter will be set to zero when the Run screen is displayed again.

Press 2 to set a new STOP count. The screen shown in Figure 2.6 will appear.

```
Enter parts count
STOP value then ENT

_____ NOW 2500
```

Figure 2.6

The STOP value sets the point at which the machine will stop and not allow the operator to continue until the counter is reset. This is useful to remind the operator when a reel is completed. The STOP value can be any number from 0 to 999,999. The STOP value currently set is displayed. To enter a new stop value, press 2, insert the number, and press ENT.

Note: If using the Coherix Vision option, set the STOP value at 0 to disable it.

During the operation, the system compares the running parts count to the preset stop value. When the count reaches the stop value, the machine stops and the controller displays a stop message on the Run screen

(Figure 2.7).

```
***STOP REACHED***
press ESC to exit

Speed Stop Count
100 2500 2500
```

Figure 2.7

Pitch

This screen (Figure 2.8) offers eight preset carrier tape pitch choices and an option to enter any other desired pitch, from 2mm to 144mm.

```
Enter desired pitch
(2-144 mm) then ENT

Now 8
```

Figure 2.8



Figure 2.9

Advance

This screen (Figure 2.10) prompts the user to enter the number of pockets to advance each time the foot switch is pressed or an advance command is sent to the controller using the I/O port.

```

Enter the number of
parts to advance
then press ENT
                          Now 10
  
```

Figure 2.10

The user can choose any value up to the maximum allowed. The maximum is the number of pockets that fit into the length of the loading track. Enter the number of pockets to be advanced and then press ENT. If an invalid value is chosen, the software will ask for another value. Choose a smaller number and press ENT again.

Speed

This screen (Figure 2.11) prompts the user to enter the speed the machine will advance the tape.

```

ENTER SPEED 5 - 250
THEN PRESS ENT
                          NOW 100
  
```

Figure 2.11

Any speed level between 5 and 250 may be entered. A recommended speed for normal operation is generally between 125 and 150.

Entering the desired setting with the keypad and pressing ENT will set the speed choice and return the user to the Setup Menu. If ESC is pressed from this screen before pressing ENT, the speed setting will not be changed.

Dwell

This screen (Figure 2.12) allows the operator to adjust the length of time the heat shoes will remain in contact with the tape during a seal stroke.

```

Enter Dwell Time
from 50 to 999 ms
then press ENT
                          NOW 400
  
```

Figure 2.12

Any value between 50 milliseconds and 999 milliseconds may be entered. The longer the shoes remain down on the tape, the stronger the resulting seal will be. A recommended dwell time for normal operation is generally around 300 milliseconds. Enter the dwell time in the space provided and press ENT.

This setting is not applicable when using PSA cover tape.

Jog

This screen (Figure 2.13) is used to adjust the position of the carrier tape in between advances.

```

KEY 0 CHANGES ADV
← FWD JOG REV →
      40 mi
  
```

Figure 2.13

This is useful, for example, to line up the carrier pockets with an inspection camera or with a reference point for counting the first and last pocket of a run. The default jog distance is approximately 40 microns (.0016 inches). Pressing the 0 (zero) key will toggle the jog distance from 40 microns to 2 mm increments and back again.

To move the tape, press the arrow key on the keypad pointing in the desired direction. The tape will jog the selected distance each time an arrow key is pressed. When the tape is positioned correctly, press ESC to exit.

Mode

This screen (Figure 2.14) is used to set the sealer type to be used and enable other sensors and options.

```
1>HEAT SEAL*
2>PSA SEAL
3>SENSORS
4>INTEGRATION
```

Figure 2.14

Heat Seal

When heat seal is selected, the sealer dwell time value is displayed on the Run Screen. The heat seal switch on the sealer controls panel must be turned ON in order for the heat sealer to operate.

PSA Seal

If the system is switched to the PSA mode, the heat seal switch should be turned OFF. The dwell time value will be replaced by the letters PSA on the Run Screen and the temperature alarm is deactivated. Because no dwell time is involved, the TM-50 has greater throughput with a PSA sealer than with a heat sealer since it does not need to pause every few pockets for the sealer shoes to drop.

An asterisk will appear after HEAT SEAL or PSA SEAL to indicate which is currently enabled.

Sensors

The TM-50 may have the optional sensors installed for empty pocket detection, low covertape detection, low carrier tape detection, and/or carrier motion detection. Choice 3> toggles the use of the sensors installed to enabled or disabled.

Integration

This screen (Figure 2.15) is used to set how the tape advance will function with the foot switch.

```
1>Single Feed*
2>Continuous Feed
```

Figure 2.15

When SINGLE FEED is selected, the tape will begin to advance when the foot switch is pressed and stop when the foot switch is release. The tape will be advanced continuously only when the foot switch is held down. When CONTINUOUS FEED is selected, the tape will begin to advancing when the foot switch is pressed and released and continue to advance until the foot switch is again pressed and released. With the continuous feed option, it is not necessary to hold the foot switch down to advance the tape continuously.

Run

When RUN is selected, this screen (Figure 2.16) will be displayed and the TM-50 will ready to operate.

Pitch	V-TEK	Dwell
8	Advance	PSA
Speed	Stop	Count
100	2500	

Figure 2.16


The parameters which have been entered are displayed on the screen along with the running parts count. The TM-50 will begin to advance and seal tape when the foot switch is pressed.

Forcing a Seal Stroke

Pressing ENT while in the run screen, or at the power-up screen will cause the sealer head to stamp a single seal, without any advance of the carrier occurring.

Power Recovery

The power recovery feature recovers lost motion in the event of a power loss. When the machine loses power during a tape advance move, the following screen (Figure 2.17) will be displayed when the machine is power again and Run Mode is entered.



```
Power loss noticed.  
Continue last move?  
<- No           Yes ->
```

Figure 2.17

Selecting YES will add the lost move to the end of the next advance.

Extended Software Option

The extended TM-50 software option improves on the system control with a number of additional features.




Figure 2.18

The menus found in the extended software for the controller functions the same with the additional features discussed below.

The opening screen, as shown in Figure 2.18, includes an option to choose a previously programmed job configuration. Pressing 0 opens a screen (Figure 2.19) that allows the user to enter a job number from 1-64.




Figure 2.19

The job number chosen must have been fully programmed and saved prior to calling it up. Enter the number and press ENT and the system will immediately enter the run mode with all parameters set.

The initial setup screen is slightly different from that of the standard TM-50 software. It is

comprised of a two screen menu shown in Figure 2.20.





Figure 2.20

ure 2.20.

While most of the option screens are unchanged from the standard software menus, the 7>MODE choice allows extended features to be accessed.

Selecting 7>MODE from the setup screen will bring up the menu shown in Figure 2.21.




Figure 2.21

Selecting either heat or PSA seal will choose the mode of sealing. An asterisk indicates the mode currently set.

Pressing 3>SENSORS will bring up the screen shown in Figure 2.22.




Figure 2.22


These choices allow the user to toggle each of the listed the sensors installed on the machine to ON and OFF. An asterisk indicates the option is turned ON. If the sensors listed are not present on the machine, do not enable them in this software screen.

EPD

EPD is the empty pocket detection system. It is self initializing if turned ON. It will not cause a fault signal until after the first part is seen, or 300mm of carrier tape has passed under it.

Track Jam

The two track jam sensors watch for parts that are riding on top of the carrier tape or otherwise not in their pockets properly. Sensor 1 is located on the right end of the track. Sensor 2 is located on the left side of the track, near the Sealer (pictured below).



If a jam occurs, the controller display will alert the user.

JAM ON SENSOR 1
PLEASE CORRECT THEN
PRESS ESC

Low Cover

The low cover sensor monitors the quantity of cover tape that remains on the reel. It will fault if it becomes too low.

Carrier Motion

The carrier motion sensor monitors the movement of the carrier tape to assure it is moving.

Low Carrier

The low carrier sensor monitors the quantity of carrier tape that remains on the reel. It will fault if it becomes too low.

Pressing 4>INTEGRATION on the MODE screen will bring up the screen shown in Figure 2.23.

```
1>VISION MODE OFF
2>PART MARK*
3>AUTO LdrTrlr*
-->
```

Figure 2.23

Vision

The VISION option enables the TM-50 to control a vision inspection station to inspect parts while the machine is in Run Mode. When the 1 key is pressed, the display will cycle through three settings: OFF, 1, and 2.

Note: Refer to the vision system user's guide which was provided with the vision system for specific *Vision Mode* settings.

in the absence of a vision system manual, refer to the *Vision Mode Timing* section later in this chapter to determine the correct setting.

The vision inspection will occur at the end of a tape advance. The system cannot inspect components when the carrier tape is in motion. Therefore, the ADVANCE setting must be one pocket per move. Otherwise, the machine will only inspect the last pocket at the end of each tape advance.

Note: The first part placed in tape must be correctly oriented. The vision system is programmed to initiate the job lot upon detection of the first correct part.

Any empty pockets or incorrectly oriented parts will be ignored until the first correctly oriented part is inspected and the job begins.

The vision inspection will always be active in Run Mode when the VISION MODE setting is 1 or 2. Therefore, turn the vision system to the OFF setting if it is not being used in Run Mode. Otherwise, the operator will not, for instance, be able to manually run a leader or trailer in Run Mode with the vision system enabled if the system is set to fail on empty pockets.

Part Mark

Part mark causes a signal to be sent when the carrier is in motion. This is used to signal an inkjet printer to print the part information on the chip in the pocket.

Auto Leader/Trailer

The Auto Leader screen will appear as shown in Figure 2.24.

```

ENTER LEADER LENGTH
mm THEN PRESS ENT
0 and ENT = OFF
NOW 400
  
```

Figure 2.24

The automatic leader feature automatically runs out tape for the leader of the next reel once the current reel is completed. This is triggered when the STOP COUNT is reached. Using the auto leader feature both reduces time spent between finishing a reel and beginning a new and the waste of carrier tape that usually results from manually running out the tape and cutting off reels.

To enable the auto leader, determine the length of leader desired (in millimeters) to follow the last part placed and enter it on this screen. The auto leader feature is disabled when a value of zero (0) is entered.

Note: When determining the leader/trailer length, please note that the final length will be **450 mm** plus the leader/trailer length value that is entered in the controller settings.

450 mm is the approximate distance from the carrier tape cut point to the center of the placement (or inspection point if the vision option was purchased)..

If a value is entered on this screen, the screen in Figure 2.25 will appear.

```

ENTER TRAILER LENGTH
IN mm THEN PRESS
ENT.
NOW 200
  
```

Figure 2.25

Figure 2.26 indicates a typical point of reference to use as a cut point. The machine does not know at what point the operator will cut the carrier tape, therefore, the software uses this value to calculate how much total carrier needs to be run out for the end of the previous reel to reach the point the operator will cut it off.




Figure 2.26

Cut Point

Determine the distance required in millimeters and enter the value. The display will return to the Mode Screen.

When the right arrow key is pressed, a second screen of options will appear:

```
1> TAP ADVANCE
2> POWER RECOVERY
3> MANUAL/OEM=OEM
```

Figure 2.27

Tap Advance

When Tap Advance is enabled, the machine will run continuously after the foot switch is pressed and released and will not stop until the foot switch is pressed, held down for a few seconds and released again.

Power Recovery

When Power Recovery is enabled, the machine will remember at what point in an advance it had reached when power is cut. It will then automatically complete that partial advance when it is powered back up and placed into Run Mode.

Manual/OEM Mode

The Manual/OEM option will toggle between the two modes when the 3 key is pressed. When the machine is in OEM mode, it will run according to communication from a system it has been integrated with. When it is in manual mode, it will run manually with a foot switch.

The additional features are now programmed. Press ESC until reaching the setup choice screen, as shown in Figure 2.24.

Choose the NEXT key. The second screen shown will appear.

```
1>COUNT    2>PITCH
3>ADVANCE  4>SPEED
5>DWELL    6>JOG
7>MODE     NEXT  ->
```

```
8>STORE AS JOB
9>RUN THESE SETTINGS
```

Figure 2.28

It is now an option to either continue to Run Mode with the chosen settings or to save the settings to a specific job number. Select 8>STORE AS JOB to save the settings as a specific job number. The screen in Figure 2.25 will appear.

SAVE AS JOB NUMBER

Figure 2.29

Enter a two-digit number between 01-64 as the desired job number. Press ENT to save the job. In the future, the saved settings can quickly be recalled and used by selected the job number to which they have been assigned.

All features not in use (such as sensors not present) must be turned OFF when you save or run the settings from a job number.

Using the Vision Port

It is simple to use a vision system with the TM-50. Connect as indicated by the diagram shown in Figure 2.30. All input and output from this port is open collector/drain. Signals are referenced to the 0V ground pin (DB9-5).




Figure 2.30

Vision I/O Receptacle

1. INPUT: BUSY Signal
2. Not Used
3. INPUT: Part PASS/FAIL Signal
4. OUTPUT: TRIGGER (Start of Test)
5. Signal Ground
6. 24V DC
7. Not Used
8. Not Used
9. Not Used

Note: Beginning with Software Revision 1.74, the TM-50 will respond as indicated below.

Vision Mode I

1. The TM-50 will pull the TRIGGER signal (DB9-4) low.
2. The TM-50 will now wait until the vision system returns a BUSY signal (DB9-1) by pulling low. This indicates to the TM-50 that the vision has begun a test sequence.
3. Once the BUSY signal is seen, the TM-50 will release the TRIGGER signal.
4. The TM-50 will now wait until the BUSY signal is returned high. When it is returned, the TM-50 will inspect the PASS/FAIL signal (DB9-3) to determine if the part has passed. A logic low on this signal will be interpreted as a FAIL.

Note: A screen will appear if a failure is seen. Correct the problem and then press ENT to retest the part, or press ESC to accept the part, count it, and move on.

It is important to note that if the BUSY signal is not received as indicated in Step 2, the TM-50 will remain in a BUSY state and the TRIGGER signal will remain low. This may occur if there is a vision system failure or if the vision is not turned ON. Correct the problem, then press any key on the keypad, and the TM-50 will release the TRIGGER and move on.

V-TEK recommends the following timing values for *Vision Mode 1*.

Vision Mode I Timing




Figure 2.31

Vision Mode 2

DB9-1 is not used as a BUSY signal in this setup to allow Vision Systems without BUSY signals to be integrated. In this instance, identical signals on both DB9-1 and DB9-3 are needed.

1. The TM-50 will pull the TRIGGER signal (DB9-4) low for 10ms.
2. The TM-50 will now start looking at the DB9-1 signal and the DB9-3 signal from the vision system. The TM-50 will search for 100ms time frame.
 - For a PASS condition to occur, DB9-1 and DB9-3 must be pulled low for 100 ms. These signals must begin within the TM-50's search time frame.
 - If no signal is seen in that time period or if only one signal is seen, a part FAIL condition will occur.
3. The TM-50 will now look for the next TRIGGER signal.

Note: A screen will appear if a failure is seen. Correct the problem and then press ENT to retest the part, or press ESC to accept the part, count it, and move on.

The TM-50 will not fail any parts until it has seen the first good part. This prevents failure notices before the first part reaches the camera.

V-TEK recommends the following timing values for *Vision Mode 2* for a PASS condition.

Vision Mode 2 Timing




Figure 2.32

Note: If only one *Pass/Fail Line* is used with the vision system, the *Busy Line* (pin 1) and *Pass/Fail Line* (pin 3) can be jumped together.

Vision Hookup Example




Figure 2.33

Using the Comm Port

If the TM-50 is connected to the serial port of a computer, the computer can call up any of the preprogrammed jobs. Send the number 01--64 to the TM-50 and it will immediately load that job and go into run mode. If the job number is accepted, the TM-50 will return the letters "OK." If it is out of range and not accepted, it will return the letters "NO." These job calls are accepted either at the first power-up screen or when in the run mode. Only at these points will it be recognized. The parameters of the port are 19200 baud, 8 bits, no parity, and 1 stop.

Refer to Figure 2.34 for the following information:

1. NC
2. TX
3. INPUT: RX
4. NC
5. Signal Ground
6. Not used
7. Not used
8. Not used
9. Not used





Figure 2.34

Using the Sensor Pass Through

All of the sensors that the TM-50 monitors are also available as passed through outputs. The extended software is not needed for self monitoring. All of the sensors are open collector devices and can easily be interfaced. Refer to Figure 2.35. The pinout of the port is as follows:

1. Fault - High Impedence
2. Track Jam 2
3. Print
4. System Ground (OV)
5. Not Used
6. Not Used
7. Track Jam 1



Sensor Out

Figure 2.35

Note: The **Sensor Out** and **I/O Ports** are customized for BP Micro. Some sensor outputs are in the **I/O Port** and some outputs are in the **Sensor Out Port**.

See **Chapter 4: Maintenance: Electrical Connections** for additional information.

Chapter 3: Setup and Operation

Contents

Preparing to Run a Job	30
Quick Setup Guide	30
Preparing to Run a Job	31
Heat Seal Setup	36
PSA Seal Setup	39
Testing Seal Strength	40
Operation	41
Using the Empty Pocket Detector	43
Using E-Stop in Malfunction/Fail Situations	45

Preparing to Run a Job

The *Quick Setup Guide* below provides a brief outline of the setup steps to get seasoned operators up and running quickly. Detailed, step-by-step instructions follow in the sections ahead.

Quick Setup Guide

1. Connect power and air supply.
2. Check to ensure foot switch, peripheral cable, and optional vision, sensor and communication ports are connected.
3. Turn the TM-50 Controller ON.
4. Load carrier tape.
5. Load cover tape.
6. Load an empty take-up reel.
7. Select Heat or PSA Seal.
8. Setup the Sealer.
9. Perform a Seal Test.
10. Perform a Peel Force Test.
11. Set Tape Advance speed.
12. Create the Trailer.
13. Check the Carrier Tape Alignment.
14. Set the Counter.
15. Run the job.



Caution!


V-TEK® Incorporated takes no responsibility for the safety of the OEM TM-50 if it is used for any purpose other than the intended purpose as specified in this User's Guide.

Setup

Connect Power and Air Supply

1. Ensure the power and compressed air supplies are connected to the machine, as described in Chapter 1.

Note: The air pressure should be set somewhere between 80 psi, the minimum recommended air pressure, and 110 psi, the maximum recommended air pressure.



2. Turn the machine on by pulling out the power button on the front of the controller.




Figure 3.1

Set the Controls

1. Turn the take-up reel tension adjust knob fully counterclockwise to zero to more easily place a new take-up reel onto the take-up spindle.
2. Set the taping job parameters through the controller.

Load Tapes




Figure 3.2

Adjust the Width of the Loading Track

The width of the loading track adjusts by moving the front track in and out on two shafts. The shafts have detents that engage the front track at standard widths to accommodate 8-56mm carrier tapes. The track is adjusted by loosening the three *Thumb Screws* in the *Slotted Track Cover* and then pulling or pushing the front track until the correct detent is engaged on both sides. If it is unclear which position is needed, use a sample of the carrier tape that will be loaded and compare it to the track. Adjust the loading track as necessary if it does not fit.

Mount the Carrier Tape Reel

1. Remove the *Carrier Tape Quick Lock* from the *Carrier Tape Spindle*.

Note: To remove the *Quick Lock* mechanism from the cover tape support arm, pull the two metal disks apart and slide the Quick-Lock off the spindle.



Figure 3.3

2. Mount the bulk *Carrier Tape Reel* on the spindle so the tape unwinds from the top and the sprocket holes of the carrier tape are on the inside for tape widths less than 32mm. Tapes wider than 32mm have holes on both sides. Usually, the outside holes of these larger carrier tapes are slightly oval in shape.

3. Replace the *Quick Lock* and position it so the reel is supported and spins freely on the spindle with little or no drag.

4. Trim the end of the carrier tape so it is clean and straight.



Figure 3.4

Route the Carrier Tape

1. Guide the carrier tape into the *Loading Track*.




Figure 3.5

2. Begin by routing it over the *Tape Guide* that is situated below the loading track.




Figure 3.6

3. Guide the carrier tape over the (2) *Tape Guides* which are located at the right end of the *Loading Track*.

It should feed through the loading track easily. Lowering the *Feed Reel Support Arm* can reduce drag if the angle at which the carrier enters the loading track is too steep.




Figure 3.7

4. Bring the end of the carrier tape past the *Sealer* and engage the sprocket holes on the teeth of the *Drive Sprocket*. If the loading track is slightly askew, the carrier tape may not feed to the sprocket easily. If so, readjust the track with the track gauge.




Figure 3.8

Mount the Cover Tape

1. Place a reel of cover tape of the correct width to match the carrier tape on the *Cover Tape Spindle*. The tape should unwind to the right from the bottom of the reel.

Note: To remove the *Quick Lock* mechanism from the cover tape support arm, pull the two metal disks apart and slide the *Quick-Lock* off the spindle.



Figure 3.9



2. Set the width of the *Cover Tape Guide Assembly* by loosening the red knob on the assembly and holding the cover tape against the inside of the guide. Slide the outside guide toward the tape until it touches it. Tighten the knob.

3. The position of the *Cover Tape Guide* can be adjusted using the *Cover Tape Position Adjuster*. Turning it clockwise will move the cover tape position toward the sprocket side of the tape.

4. Using blue tabbing tape, attach the cover tape to the carrier tape. Thread both through the *Cover Tape Guide Sealer Assembly*. Run the machine to advance the carrier and cover tapes through the *Sealer*.

5. Check the tension of the cover tape by observing if there is excess slack as the cover tape is pulled through the sealer. If so, the tension is too little. If there is no slack, check that the tension is not too tight by pulling the tape by hand. If the tape does not unwind easily, it is too tight. In either case, poor seal consistency can be a problem.

Adjust the cover tape tension by turning the *Tension Adjustment Knob* on the back of the *Cover Tape Arm* clockwise (in) to increase tension. The goal is to tighten the cover tape so there is not excess freedom in the tape when it is advanced.

Note: Check to ensure that the outside reel cover is not pressed too tightly against the cover tape reel. This may interfere with the reel, creating tension problems.






Figure 3.10

Tension Adjustment Knob



Quick Lock Back Reel Cover



Front Reel Cover

Figure 3.11

Heat Seal Setup

If a *PSA Seal* is desired, proceed to the next section.

1. If the TM-50 was previously used for *PSA Seal*, loosen the *Seal Roller Pressure Screws* until the *Sealer Rollers* are no longer in contact with the tape.




Figure 3.12

2. Make sure the power to the TM-50 is **ON**.



Figure 3.13

3. Turn the heat seal switch **ON**.



Figure 3.14

4. Set the temperature controls to the appropriate temperature. Refer to the table below or to *Appendix B: Temperature Controller Default Settings*.

CARRIER TAPE TYPE	COVER TAPE TYPE	TEMPERATURE IN CELSIUS	PRESSURE IN PSI	DWELL TIME IN MILLISECONDS
CONDUCTIVE BLACK POLYCARBONATE	STATIC DISSIPATIVE COVER	135-155°	40-60	250-400
NON-CONDUCTIVE CLEAR POLYCARBONATE				
CONDUCTIVE BLACK POLYSTYRENE				

Note: The TM-50 accommodates a wide range of carrier tapes and cover tapes. Settings may vary from one tape product to another.

The settings in the table above are suggested starting points only. The temperature of each shoe can be increased or decreased according to the results of a peel force test.

5. Adjust the heat shoe air pressure to the appropriate setting. The recommended starting point is **50 psi**. Turning the *Pressure Adjust* knob clockwise will increase the pressure, while turning it counterclockwise will decrease the pressure. This setting controls the amount of force applied when the sealer shoes drop.

Note: Maximum suggested air pressure is 110 psi.



Figure 3.15

6. Allow the *Heat Sealer* to reach its operating temperature before continuing.



Temperature Hazard!

Touching the heat block guard while the Heat Sealer is in operation may result in burns. Use care when working near this area and allow it to cool before performing maintenance.

7. Set the *Controller* parameters need for the current job and then place the machine into *Run Mode*. Refer to the *Controller* chapter for additional information about setting the controller parameters.

8. Advance the tape using the *Foot Switch*.

9. Check the sealed tape for the desired seal position.




Figure 3.16

The width of the *Sealer Shoe* positions is adjusted by the white, toothed seal position adjusters on either side of the sealer. Turning the adjuster clockwise or counterclockwise will adjust the *Sealer Shoes* to a narrower or wider position.

Inner Seal Position

The inner seal shoe is adjusted by the *Inner Seal Position Adjuster*. Turning the adjuster clockwise will move the seal away from the operator. Turning the adjuster counterclockwise will move the seal toward the operator. Adjust to the desired position. Once the position has been adjusted, tighten the position lock to secure it.

Outer Seal Position

The outer seal shoe is adjusted by the *Outer Seal Position Adjuster*. Turning the adjuster clockwise will move the seal toward the operator. Turning the adjuster counterclockwise will move the seal away from the operator. Adjust to the desired position and then lock it into place using the position lock knob.

10. Adjust the *Heat Sealer* temperature setting until the cover tape adhesive is fused to the carrier tape.

PSA Seal Setup

1. Turn the heat seal switch **OFF**.



Figure 3.17

2. Refer to the *Controller* chapter to set the controller to PSA operation and place it in the *Run Mode*.
3. Advance the tape using the *Foot Switch*.
4. Adjust the *Inner* and *Outer Seal Roller Position* using the white *Seal Position Adjuster Knobs* on either side of the *Heat Sealer*. . Align the roller position over the strip of adhesive on either side of the PSA cover tape.




Figure 3.18

5. On the top of each *Sealer Block*, there are three holes with a screw in the center hole. While spinning the *Sealer Wheel*, turn the screw clockwise until the wheel no longer spins freely, then turn the screw another 1/8 turn. The wheel should be firmly in contact with the tape. Experience will allow the operator to judge the correct adjustment by feel. Repeat for the other *Sealer Wheel*.
6. Advance the tape through the TM-50 using the *Foot Switch*. Adjust the *Seal Roller Pressure* until the PSA adhesive is firmly adhered to the carrier tape.

Note: Excessive roller pressure may cause carrier tape advance problems or elongation of sprocket holes in the carrier tape.

Testing Seal Strength

Perform a Test Seal

1. Run the tape through the *Taping Module* by pressing the *Foot Switch*.
2. As the seal is occurring, watch the alignment of the cover tape with the carrier tape. The cover tape should run exactly in the groove of the *Cover Tape Guide* and the seal should appear as a solid, consistent line.
3. Adjust the seal positions as described in the sealer setup sections above, if necessary.

Perform a Peel Force Test

For most taping applications, a *Peel Force Test* is needed to determine the seal characteristics. Perform as many *Peel Force Tests* as needed while adjusting the sealer controls to obtain the required seal strength.

Instructions for *Peel Force Test* vary from one manufacturer to another. Follow the manufacturer's instructions for the *Peel Force Tester* selected to perform the test. A V-TEK *PT-55 Peel Force Tester* is pictured below.



Operation

Once carrier tape and cover tape have been loaded, sealer setup is complete and the controller settings are selected, the OEM TM-50 is ready for operation.



Caution!

V-TEK® Incorporated takes no responsibility for the safety of the OEM TM-50 if it is used for any purpose other than the intended purpose as specified in this User's Guide.

Mount a Take-up Reel

Mount an empty *Take-up Reel* on the *Take-up Reel Spindle*. The width of the reel must match the width of the carrier tape and its diameter should be large enough to accommodate the number of components in the taping job.

Setup the Sealer

If the new job requires a change of sealer type (from *Heat Seal* to *PSA*, for instance) or size of carrier tape, setup the *Sealer* for the new settings as described above in the *Heat* and *PSA Setup* sections above.

Perform a Test Seal

Run the tape through the *Taping Module* by pressing the *Foot Switch*. As the seal is occurring, watch the alignment of the cover tape with the carrier tape. The cover tape should run exactly in the groove of the *Cover Tape Guide* and the seal should appear as a solid, consistent line. Adjust the seal positions as described in the *Sealer Setup* sections above, if it is necessary.

Perform a Peel Force Test

For most taping applications, a *Peel Force Test* is needed to determine the seal characteristics. Perform as many *Peel Force Tests* as needed while adjusting the sealer controls to obtain the required seal strength.

Create the Trailer

Leader/Trailer

Before beginning a production reel, determine how long the trailer and the leader should be. The terms “leader” and “trailer” refer to the lengths of empty carrier tape required at the beginning (leader) and the end (trailer) of the finished reel of placed parts. Therefore, when the reel is being taped on the TM-50, the trailer is the first length of empty carrier tape run before the first part is taped and the leader is the length of empty carrier tape run after the last part is taped.

After the cover tape alignment and any *Peel Force Tests* are completed, run out enough sealed empty pockets to make the trailer that is required for the current job.

Check Carrier Tape Alignment

To ensure an accurate count, select a spot on the loading track as a reference point for the first and last parts counted. Examples of reference points include the edge of the stainless steel *Carrier Tape Guide*, one of the fastener heads, or the *Track Width Lock Knob*.


Set the Counter

Set the counter **STOP** value in the *Controller* menu to the batch size to be run, if necessary, and then reset the counter to zero.

Place Components

Place components in carrier pockets until the *Loading Track* has been filled, then tape them by pressing the *Foot Switch*.

Note: When placing components operators should change positions frequently and take periodic breaks to avoid fatigue and repetitive stress injuries. Consult your employer for guidelines specific to your workplace.



Examples of Ref. Points

Figure 3.19




Figure 3.20

2. Observe the carrier tape as it advances to confirm it is moving smoothly into the sealer and the cover tape is being positioned correctly. Adjust tape advance speed, seal and cover tape as needed.
3. When the end of the taped carrier reaches the *Take-up Reel*, attach it to the reel and set the *Take-up Tension Control* so that the carrier winds onto the *Take-up Reel* but does not apply excessive pressure to the carrier tape.
4. Once all components have been taped or the batch size has been reached, reset the counter to zero and run out the amount of empty carrier tape needed to make the reel's leader.

Cut the carrier tape and replaced the finished reel with a new take-up reel. Repeat the above process.

```
1>RESET count to 0
2>SET Stop value
```


REV 2.xx

Figure 3.21

Using the Empty Pocket Detector

Set up EPD

1. In the *Controller Setup Menu*, select **Mode**, and then press **3** to enable or disable the *EPD Sensor*.
2. Position the sensor over an empty pocket and press the **SET** button on the *Keyence Sensor Amplifier*. The position of the sensor can be adjusted by moving the support arm into the desired position over the track.
3. Place a component into the pocket the sensor has been positioned over and press the **SET** button again. The *Sensor Amplifier* will then be programmed to differentiate an empty pocket from a pocket with a component placed in it.



The sensor must be reset for each new type of part to be taped.

NOTE: For more information on the sensor/amplifier, refer to Appendix A: Sensors.

Operation with EPD

Operation with EPD is slightly different than operation without it.

Creating a Trailer

1. Turn the EPD OFF by selecting the Mode option in the controller setup menu, so that it will not fail the empty pockets that will run under it.
2. Without placing any parts, press the foot switch until the trailer is the desired length.
3. Reset the parts count to zero and turn the EPD back ON.

Taping Parts

1. Place the first part into the pocket that will next move under the sensor.
2. Press the foot switch once to advance the tape. After the part moves under the sensor, the EPD inspection will be made. Ensure that the **Advance** option is set to *one pocket at a time* in the *Controller Setup Menu*. Otherwise, the EPD will not function properly.

Completion

When the counter reaches the **STOP** value set in the *Controller*, the machine will stop. The last part that was counted will be under the sensor. Remove any additional parts in the loading track that may be remaining.

Creating a Leader

1. Turn the EPD **OFF** through by selecting the **Mode** option in the *Controller Setup Menu*, so that it will not fail the empty pockets that will run under it.
2. If a **STOP** value is being used, reset the parts count to **zero** in the controller.
3. Press the *Foot Switch* until the leader is the desired length.


The EPD sensing system works on a scanning system. An empty pocket seen during a tape move will be posted as a failure at the end of the move.

On some machines, the EPD option is turned on through the *Operator Interface Run Mode*. In this case, it is self enabling in operation. The *Empty Pocket Test* will not accept any fault signals until either the sensor has seen the first valid part, or 300mm of carrier tape have passed without a valid part being seen.

Using E-Stop in Malfunction/Fail Situations

There is one Emergency Stop button located on the front of the TM-50 controller. When the emergency stop is activated, all operations cease. If a jam in tape or some other malfunction occurs, follow the steps below to resolve the failure.

1. Press the red E-Stop button on the front of the controller to power the TM-50 off.



2. Disconnect the air supply.
3. Disconnect the power supply.
4. Resolve the problem.
5. Reconnect the air supply.
6. Reconnect the power supply.
7. Twist the E-Stop/Power button to turn the TM-50 back on.
8. Resume operation.

Chapter 4: Maintenance

Contents

Safe Maintenance Steps	48
Safe Maintenance Steps	49
Maintenance Instructions	50
Electrical Connections	53

Safe Maintenance Steps

Follow the steps below when performing routine maintenance or cleaning on the TM-50.

1. Turn the TM-50 **OFF**.
2. Disconnect the air supply and place the unplugged air hose so it clearly visible.
3. Disconnect the power supply and place the unplugged power cord so it clearly visible.
4. Remove all carrier and cover tape.
5. Perform cleaning/maintenance as needed.
6. Reload *Taper* carrier tape and cover tape.
7. Reconnect the air supply.
8. Reconnect the power supply.
9. Turn the TM-50 back **ON**.

Maintenance Schedule

The TM-50's simple, low-maintenance design keeps required maintenance to a minimum. The following schedule indicates common maintenance tasks and how frequently they should be performed.

Maintenance Task	Schedule	Materials needed
Heat Sealer	every 40 hours of operation	<ul style="list-style-type: none"> • 3/32" hex wrench • plastic or brass brush • alcohol
Loading Track	every 160 hours of operation	<ul style="list-style-type: none"> • small, stiff bristled paint brush
Cover Tape Guide	every 40 hours of operation	<ul style="list-style-type: none"> • alcohol • cotton swabs
Air Pressure Regulator	every 40 hours of operation	<ul style="list-style-type: none"> • none
PSA Sealer	every 40 hours of operation	<ul style="list-style-type: none"> • alcohol • cotton swabs
Fuses	replace as needed	<ul style="list-style-type: none"> • (2) 2A 5mm x 20mm SLO BLO fuses

Note: Maintenance personnel are advised not to wear loose fitting clothing or jewelry when operating or maintaining the TM-50. Only qualified personnel with the proper technical training, experience working on this type of equipment, and awareness of the possible hazards should perform maintenance on the TM-50.



Caution!

It is dangerous to service or maintain the TM-50 while it is connected to air and power supplies. Before performing any maintenance tasks, ensure the machine is stationary and disconnect the electrical and pneumatic power supplies placing the unplugged cables in clear view.

Maintenance Instructions

Heat Sealer

Heat Sealer maintenance consists mainly of cleaning built-up debris and adhesive residues from the *Heat Shoes*. It should be cleaned after every 40 hours of operation.

To clean the *Heat Shoes*, follow the steps below.

1. Make sure the *Main Power Switch* is **OFF**.
2. Loosen the *Thumb Screws* and slide the outer *Loading Track* all the way out on the *detent shafts*.




Figure 4.1

3. If the *Sealer Assembly* is still hot, allow it to cool completely before continuing.

4. Using a 3/32" hex wrench, remove the (3) BHCS and the red *Seal Position Adjuster* from the (2) sheet metal covers.

5. Clean the residues from the *Heat Shoes* by using a plastic or brass brush soaked in alcohol. **Do not use a steel bristled brush.** If there are some tough spots that will not come clean, the sealer can be heated by plugging it into the *Taping Machine*, and then scraping it with the handle of a wood brush or some other wooden implement.

Note: Do not attempt to use alcohol when the sealer is hot.




Figure 4.2

Loading Track

The *Loading Track* should be cleared of dust and debris after every 160 hours of operation.

Strip the machine, remove the *Cover Tape Guide*, and brush the dust and debris from the track with a small, stiff bristled paint brush. Excessive build-up of dirt and debris can cause carrier tape jams.

Cover Tape Guide

The *Cover Tape Guide* may become coated with adhesive and dirt during taping. It is important to keep the *Tape Groove* clean for proper alignment of the cover tape.

Clean the *Tape Groove* with alcohol and a cotton swab whenever it appears dirty. The recommended cleaning schedule is every 40 hours of operation.

Air Pressure Regulator

Inspect the *Air Regulator* for moisture accumulation after every 40 hours of operation. Turn the *Petcock* on the bottom of the *Regulator* clockwise to release the fluid if moisture is present. Tighten the *Petcock* when moisture is gone.

Note: Frequency of moisture build-up will vary with air quality. Check the *Air Pressure Regulator* periodically to determine if fluids need to be released more frequently.

Other than the release of moisture build-up, the TM-50 pneumatic system should not require adjustment or replacement.

Should an issue with the pneumatic system arise, call V-TEK Service for assistance.




Figure 4.3

PSA Sealer

The adhesive residues should be cleaned from the *Sealer Assembly* every 40 hours of operation.

Wipe the entire assembly using a cloth soaked in alcohol. Using a cotton swab soaked in alcohol, clean between the *Sealer Wheels*. Also, clean the entire surface of the black polyurethane wheel.

Note: Do not use solvents other than alcohol when cleaning the black polyurethane wheels.

If during the cleaning process the *Sealer* has become completely out of adjustment, turn the small screw behind the wheel counterclockwise approximately three turns. Slowly turn the screw clockwise while spinning the top wheel. Stop adjusting when the bottom wheel starts spinning with the top wheel.

Fuses

The machine is fused with (2) 2A 5mmx20mm SLO BLO fuses installed in a fuse holder in the *AC Filter*, just beneath the *AC Power Receptacle*. Replace as needed.

Lubrication

No lubrication is required or desired on the TM-50 as all parts are no maintenance in this regard and the use of lubricants could interfere with components.

Electrical Connections

I-O Port (J1)

All output pins of the I-O port (J1) are open collector devices.

The I-O port pins are referenced to the pin 4 ground level.

The receptacle used is an AMP 206705-1 with 66103-4 male pins. The mate would be AMP 206708-1 plug, with 66105-4 socket pins.

When the TM-50 is placed in the RUN mode at the beginning of a job, the control pins will be in the following states:

Pin 1 - Advance - Logic High 5VDC

Pin 2 - EPD Signal

Pin 3 - Ready/Busy - High Impedance

Pin 4 - System Ground (OV)

Pin 5 - End of Job - High Impedance

Pin 6 - Not Used

Pin 7 - Carrier Motion

Pin 8 - Low Carrier

Pin 9 - Low Cover




Figure 4.4

Note: The **Sensor Out** and **I/O Ports** are customized for BP Micro. Some sensor outputs are in the **I/O Port** and some outputs are in the **Sensor Out Port**.

See *Using the Sensor Pass Through* at the end of **Chapter 2: Controller** for additional information.

The sequence of the handshake controls is as follows:

1. The *Advance* pin is pulled down to a logic low, for no less than 10 milliseconds.
2. The TM-50 will set the ready/busy line low and begin the advance process. The ready/busy line will remain low until the advance is done and the heat sealing dwell time is completed. While the TM-50 is running this process, all advance commands are ignored. Upon completion of the advance/seal sequence, the busy/ready line will return to high and the next advance will be accepted.
3. When the preset stop value is reached, two things happen that can be used as job done indicators.
 - The busy/ready pin remains at a logic low.
 - The job completed pin switches to a logic low.

Releasing the busy/ready and job completed signals is accomplished by pressing the ESC key, and re-entering the RUN mode.

Interface Information

Input

Pin 1 - external advance signal - a logic low starts advance. Pin 1 is internally pulled up to 5VDC. Use an open collector device to control this pin. Do not exceed 5VDC.

Output

Pin 2 - fault signal - a logic low indicates an empty pocket or other sensor fault

Pin 3 - ready/busy signal - a logic low indicates the machine is busy

Pin 4 - logic common

Pin 5 - end of job - a logic low indicates the desired count has been reached

Pin 6 - start mark signal line (optional)




Figure 4.5

EPD Input Port

Figure 4.5 indicates the power and signal pins that are used by the EPD input port.

I-O Connector Considerations

Pin 1 is the external advance pin. This pin is to be activated by an open collector device. Pin 1 is internally pulled up to 5 VDC.

The fault output is at pin 2 of the I-O connector. When a fault is detected the output will produce a logic low.

Pins 2,3,5 are open drain mosfets. These are controlled by the TM-50 system. Each pin can sink 200ma.

All active logic signals are logic low. For example, the busy signal will be low while an advance is in progress.

The DC system within the TM-50 is isolated from the AC system. DC ground is not connected to either chassis ground or AC neutral.

For safety, connect the control system DC ground to the TM-50 I-O pin 4 DC ground. The control system DC ground should also be isolated from the AC system. However, the control system DC ground may safely be connected to chassis ground, if necessary.

If the AC system used to power the TM-50 is a single phase system, where the neutral leg connects to the chassis ground at the fuse box, DC ground could also be connected to AC neutral without problem.



WARNING! If the AC system used to power the TM-50 is a two phase system, (neither leg connects to chassis ground at the fuse box) only the chassis ground can be used as a DC common. **Connecting DC common to either power leg will result in severe damage to the TM-50.**




Figure 4.6

TM-50 POWER HOOKUP AS SEEN FROM PANEL REAR





Figure 4.7

Appendix A: Sensors

Keyence FS-N40 Series Sensor Amplifiers

The *Keyence FS-N40 Series* sensor amplifiers (shown below) are used for the taper's Empty Pocket Detector (EPD), Jam in Track Sensor and Low Cover Tape Sensor. They may also be used on the Bowl Input option, which may include Part Present Sensors.



Select the Output Mode

The FS-N40 Sensor Amplifiers can be set to two *Output Modes*: **light-ON** or **dark-ON**. This setting determines under what conditions the sensor is triggered and the *Output Indicator* is lit. In **light-ON** mode, the sensor will be triggered when the Current Value (CV) of detected light from the emitter is higher than the Preset Value (PV). In **dark-ON** mode, the sensor is triggered when the CV of detected light is lower than the PV.

1. Press **Mode (M)** once. The *Current Value (CV) Indicator* will display the current mode.



2. Press the **Manual (< >)** button to switch the output style. Select **dark-ON**. This mode is used for all TM-50 and TM-500 sensors.



- Press **Mode** (M) three times. Note that the L/D ON indicator is now set to **D-ON**



Fine Tune the Setting Value (Threshold)

Use the **Manual** (< >) button to adjust the Threshold value as desired:



- Press the left arrow to increase the setting value.
- Press the right arrow to decrease the setting value.
- Hold the button down to make adjustments more quickly.

Locking the Keys

It is sometimes desirable to lock the keys of the sensor amplifiers so that the current settings are not inadvertently changed.

- Hold down the left side of the **Manual** (< >) button and the **Mode** (M) button simultaneously for at least three seconds.



- The CV indicator will display **Loc** to indicate that the lock is in place.
- Repeat the same procedure to unlock the keys. The display will flash the message **unL**.

Initialization

To initialize all the settings and return the sensor to the original factory default settings, follow the procedure below.

1. Hold down **Set** and **ACT-R** simultaneously for at least three seconds.



2. Press **Mode** (M) once.



3. Press down the right side of the **Manual** (< >) button once.



4. Press **Mode** (M) once.



Note: Portions of this procedure were provided by:

KEYENCE CORPORATION OF AMERICA

500 Park Boulevard, Suite 200, Itasca,
IL 60143, U.S.A.

Phone: 1-888-KEYENCE (1-888-539-3623)

For detailed instructions, visit www.keyence.com and download the *Keyence Digital Fiberoptic Sensor FS-N40 Series Instruction Manual*.

Appendix B: Temperature Controllers

Contents	
Omron E5GC Temperature Controller	B-2

Omron E5GC Temperature Controller

The Omron E5GC Temperature Controller is used to monitor and maintain a target temperature range for the sealing shoes of the heat sealer. The heat sealer is equipped with two controllers, which control the two sealer shoes (inside and outside) independently. The controllers are set by default to maintain a temperature range equal to the set point ± 10 degrees for their respective sealer shoe. The controller does this by comparing the present value (current temperature) to the set point (target temperature). It turns on the heating element in the sealer shoe whenever the present value drops to 10 degrees below the set point and allows them to cool when the present value rises to 10 degrees above the target temperature.

Adjusting the Set Points

To adjust the set point, simply press the increment or decrement keys (up and down arrows). The green Set Point Display will show the changes and the controller will immediately begin adjusting the temperature of the sealer shoes according to the new range that results. If a large adjustment is required, pressing and holding the up or down arrow keys will increase or decrease the set point quickly.

Default Factory Settings

Refer to the Omron E5GC User's Guide when necessary for more detailed technical information regarding the operation of the temperature controllers. The directions below describe the factory settings set at the time the controllers are installed at V-TEK, Inc.

Operation Level Settings (Figure 1.1)

1. Select the *Run-Stop Settings*, displayed as **r-S**, by pressing the Mode Key. It should be set to **rUn**.
2. Select the *Upper Limit Alarm*, displayed as **AL 1H**. It should be set to **10**.
3. Select the *Lower Limit Alarm*, displayed as **AL 1L**. It should be set to **10**.




Figure 1.1




Figure 2

Setting Protection Levels (Figure 1.1)

1. Press and hold the level and mode keys for at least three seconds. The controller will enter *Protect Level*.
2. The first parameter, *Operation/Adjustment Protection*, will read as **oAPt** on the PV display. It should be set to **0**. If not, make adjustments with the Up or Down Arrow Keys.
3. Press the Mode Key. This moves to the *Initial Setting/Communications Protection* parameter, which will read as **iCPt**. It should be set to **1**.
4. Press the Mode Key again. This moves to the *Setting Changes Protection* parameter, which will read as **utPt**. It should be set to **off**.




Figure 1.1

Initial Settings (Figure 1.2)

1. Press the Level Key for at least three seconds. The PV display will flash after one second and temperature control will stop. The controller is then in *Initial Settings Level*.
2. The *Input Type* parameter will display as **In-T**. It should be set to **7**. This setting corresponds to the J type thermocouple used in V-TEK sealers.
3. Select the *Temperature Unit* parameter, displayed as **d-u**, by pressing the Mode Key. It should set to **C**, which selects Celsius.
4. Select the *Control Period* parameter, displayed as **CP**, by pressing the Mode Key. It should be set to **5**.
5. Select the *Direct/Reverse Operation* parameter, displayed as **orEu**. It should be set to **or-r**.
6. Select the *PID/On-Off* parameter, displayed as **CntL**. It should be set to **Pid**.
7. Select the *Self-tuning* parameter, displayed as **St**. It should be set to **off**.
8. Select the *Alarm Type* parameter, displayed as **ALt1**. It should be set to **1**.
9. Select the *Set Point High Limiter*, displayed as **sl-H**. It should be set to **850**.
10. Select the *Set Point Low Limiter*, displayed as **sl-L**. It should be set to **-100**.




Figure 1.2

Adjustment Level Settings (Figure 1.3)

1. While still in the *Initial Settings Level*, press the Level Key once for less than one second. The controller will enter the *Adjustment Level*.
2. The initial parameter displayed is the *Auto-tuning* parameter, displayed as **At**. It should be set to **off**.
3. Select the *Temperature Input Shift* parameter, displayed as **inS**, by pressing the Mode Key. It should be set to **0.0**.
4. Select the *Proportional Band* parameter, displayed as **P**. It should be set to **20**.
5. Select the *Integral Time* parameter, displayed as **i**. It should be set to **42**.
6. Select the *Derivative Time* parameter, displayed as **d**. It should be set to **7**.
7. Press the Level key again for less than one second. The controller will return to normal operation.




Figure 1.3

Calibration Procedure

Calibrate the temperature controllers as needed, following the steps below:

1. Measure the temperature of the seal shoe at the end of the thermocouple with the temperature probe.
2. If the temperature reading on the controller is different than that of the probe, adjust the temperature input shift value in the *Adjustment Level* of the temperature controller.

Example: If the controller reading is 140 degrees C and the probe reading is 115 degrees C, set the *Temperature Input Shift Value* at -15 degrees C.

3. Press the Level Key for less than a second. Then select **inS**. Enter **-50** with the up/down arrow keys. If the controller reading is higher than the probe reading, the input shift entry should be a negative number. If the probe is higher, the entry should be a positive number. Re-check both readings and continue to adjust the input shift until the controller and probe readings are within +/- 5 degrees C of each other.

Spare Parts List

OEM TM-50

Part Number	Description	Quantity
Controller		
102035	LCD display	1
103499	Transformer (new style)	1
103504	Transformer (old style)	1
105401	Firmware & chip*	1
109091	Membrane Keypad	1
112557	Fuse 2 amp (5x20 mm)	1
150032	AC auto select board (new style)	1
150038	AC auto select board (old style)	1
152101	Foot switch assembly	1
157029	Power supply 24 VDC	1
291963	Tension Control Board Replacement Kit	1
292763	Main Control Board Kit	1
<i>* Please provide Software version when ordering.</i>		
Base Machine		
105573	Gear head 50:1	1
105659	Stepper motor/drive	1
105695	Take-up motor	1
105705	Temp-controller	2
150045	Step-seal circuit board	1
150050	Solenoid board	1
200029	Sealer air cylinder	2
200030	Sealer air cylinder	2
200603	Sealer air valve	2
200801	Air pressure gauge	1
204055	Drive idler bearing	2
204056	PSA wheel bearing	4
210019	Timing belt	1
212008	Drive idler o-ring	2
217007	Large black knob	2
217042	Small red knob	4
244007	Heat seal thermocouple	2
244008	Heat seal heater	2
250159	Lower-seal roller	2
253780	Take-up reel spindle (72 mm)	1
257999	Take-up reel spindle key (72 mm)	1
260574	Idler arm	1
260576	Drive idler	1
261096	Track setup gauge	1
261122	Heat shoe	2
266737	Drive sprocket (50 pin)	1
267573	Upper-seal roller	2
290603	Upper Roller Assembly (with bearing)	2
290604	Lower Roller Assembly (with bearing)	2


Spare Parts List

Dual Jam OEM TM-50 Sensors


Part Number	Description	Quantity
EPD Sensor		
104949	FS-N41N Amplifier (new style)	1
104951	FS-V11 Amplifier (old style)	1
104952	FU-35FA Fiber Optic	1
EPD Black Position Knob		
217022	Black Cap	1
261268	Thumbscrew Knob	1
Low Cover Tape Sensor		
104949	FS-N41N Amplifier (new style)	1
104951	FS-V11 Amplifier	1
104952	FU-35FA Fiber Optic	1
Cross Track Sensor		
104950	FS-N42N Amplifier	2
105123	FU-57TZ Fiber Optic Sensor	2
Carrier in Motion Sensor		
105048	EX-11A SUNX Sensor	1

8 7 6 5 4 3 2 1


D




C



B



A




D

C

B


A


REVISIONS				
ECO #	REV.	DESCRIPTION	DATE	APPROVED
	A	RELEASE	4/4/13	
2795	B	UPDATE BOM TO AS BUILT	5/1/14	RH
2806	C	REMOVE PART 111106	6/17/2014	RH
2816	D	ADD (3) 217019 KNOBS AND REMOVE CABLE 151529 FROM THE BOM	10/8/2014	RH
2836	E	REPLACE PART NUMBER 250309 WITH PART NUMBER 267573	11/18/2014	RH
2850	F	REPLACE PART NUMBER 111128 WITH PART NUMBER 111169	3/30/2015	RH
2942	G	ADD SHIPPING PLATE 261373	5/8/2017	PVO
3019	H	REPLACE (105012) AND (105013) WITH (105151) AND (105149)	1/11/2018	PVO

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	 THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MINNETONKA, MN.	
DIMENSIONS ARE IN INCHES		DRAWN	RH		
TOLERANCES: .XX ± 0.005 XX ± 0.010 X ± 0.015		ENG APPR.	RH		
ANGULAR: MACHINED ± 0.1° BEND ± 0.5°		TITLE:		TM-50 OEM DUAL JAM	
SURFACE: 32/		MATERIAL		SIZE	DWG. NO.
GENERAL NOTES: - INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5 - BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED - CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED - ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART - DO NOT SCALE DRAWING		FINISH		B	291633
				WEIGHT (lbs): 92.20	REV H
				SHEET 1 OF 20	

8 7 6 5 4 3 2 1



					
	NAME	DATE			
DRAWN	RH	2/11/2014	THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANKATO, MN.		
ENG APPR.	RH	-			
TITLE:					
TM-50 OEM DUAL JAM					
4.5 NOTED SES	MATERIAL	SIZE	DWG. NO.	REV	
	FINISH	B	291633	H	
			WEIGHT (lbs): 92.20		SHEET 3 OF 20





ITEM NO.	PART NUMBER	DESCRIPTION	QTY
62	204051	BEARING, 3/8ID X 7/8OD	4
63	204052	BEARING	4
65	204055	BEARING SFR-188ZEE	11
70	207022	SPACER 1/4 X .016	2
71	207025	SHIM, 3/8 ID, 9/16 OD, .010 THICK	1
73	209022	SPRING, TORSION RIGHT HAND WOU	1
79	211018	PULLEY, .080 PITCH X 120 GROOVE	1
80	212008	ORING 028 NEOPRENE	2
92	219010	1/8 X 3/8 LG. SS DOWEL PIN	1
93	219015	1/4 X 1 LG. SS DOWEL PIN	6
105	221015	SHCS SS 6-32 X 1/2	8
109	221027	SHCS SS 8-32 X 1/2	6
111	221029	SHCS SS 8-32 X 3/4	6
118	221062	SHCS SS 1/4-20 X 5/8	4
119	221063	SHCS SS 1/4-20 X 3/4	18
120	221064	SHCS SS 1/4-20 X 1	1
134	223043	BHCS SS 10-24 X 1/4	3
136	223059	BHCS SS 1/4-20 X 3/8	5
141	225001	FHCS SS 4-40 X 1/4	13
144	230016	8-32 X 1/8 STEEL SET SCREW	1
147	230023	10-24 X 3/16 STEEL SET SCREW	5
148	230071	10-24 X 5/16 STEEL SET SCREW	5
151	234013	1/4 X 5/8 SLOTTED SHOULDER SCREW	1
170	249971	MCMASTER CARR (98408A120)	2
171	250015	BEARING MOUNT	1
186	255590	DRIVE SHAFT	1
196	258574	FRONT GUIDE SHAFT	1
198	260574	IDLER ARM	1
199	260576	DRIVE IDLER	1
200	260577	IDLER ARM SHAFT	1
213	261060	SHAFT, THREADED ADJUSTER	2
217	261068	SHAFT, IDLER ADJUSTER	1
228	261098	GEAR MODIFICATION, 34T	2
256	266736	SPROCKET GUARD	1
257	266737	DRIVE SPROCKET, 50 PIN	1
258	266738	SHORT TRACK COVER	1
259	266746	SHORT REAR TRACK	1
260	266747	SHORT TRACK COVER #2	1
261	266748	TAPE GUIDE MOUNT	1
273	266992	REAR TAPE GUIDE	1
275	266994	TAPE GUIDE WHEEL REAR	1
277	266996	WHEEL AXLE	2
278	266997	REAR TRACK BPM	1

UNLESS OTHERWISE SPECIFIED:		NAME	DATE
DIMENSIONS ARE IN INCHES		DRAWN	RH 2/11/2014
TOLERANCES: .XX ± 0.005		ENG APPR	RH -
XX ± 0.010		TITLE:	
X ± 0.015		TM-50 OEM DUAL JAM	
ANGULAR: MACHINED ± 0.1°		MATERIAL	SIZE DWG. NO. REV
BEND ± 0.5°		FINISH	B 291633 H
SURFACE: 63		WEIGHT (lbs): 92.20	
GENERAL NOTES:		SHEET 4 OF 20	
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5			
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED			
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED			
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES			
MUST RESULT IN ROHS COMPLIANT PART			
- DO NOT SCALE DRAWING			




THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.



DETAIL A
MOTOR MOUNT SCREW LOCATION
SCALE 1:3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
25	105659	MOTOR, STEPPER IMS-23 (MICRO)	1
77	210019	BELT TIMING (TB20UP6-105)	1
78	211013	PULLEY, 24T	1
114	221045	SHCS SS 10-24 x 5/8	4
118	221062	SHCS SS 1/4-20 X 5/8	4
193	256607	MOTOR MOUNT	1

UNLESS OTHERWISE SPECIFIED:			NAME		DATE	
DIMENSIONS ARE IN INCHES			DRAWN	RH	2/11/2014	
TOLERANCES: .XXX ± 0.005						
XX ± 0.010			<div></div> <div>THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.</div>			
X ± 0.015						
ANGULAR: MACHINED ± 0.1°						
BEND ± 0.5°						
SURFACE: 63			TITLE:			
GENERAL NOTES:			TM-50 OEM DUAL JAM			
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5			MATERIAL	SIZE	DWG. NO.	REV
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED						
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED			FINISH	B	291633	H
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN RoHS COMPLIANT PART						
- DO NOT SCALE DRAWING						
			WEIGHT (lbs): 92.20		SHEET 5 OF 20	




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
32	111002	SAFETY STICKER HAND BURN	1
64	204055	BEARING SFR-188ZZEE	11
87	217042	KNOB M4 RED	3
90	219004	1/8 X 7/8 LG. SS DOWEL PIN	2
92	219015	1/4 X 1 LG. SS DOWEL PIN	6
93	219017	1/4 X 1-1/2 LG. SS DOWEL PIN	2
94	219043	3/16 X 5/8 LG. SS DOWEL PIN	2
107	221026	SHCS SS 8-32 X 3/8	3
118	221063	SHCS SS 1/4-20 X 3/4	18
140	225001	FHCS SS 4-40 X 1/4	13
146	230023	10-24 X 3/16 STEEL SET SCREW	5
212	261060	SHAFT, THREADED ADJUSTER	2
215	261064	COVER, TRACK SHORT	1
226	261097	GEAR MODIFICATION, 30T	1
234	261682	MOUNT OUTER ANVIL	1
235	261683	FRONT TRACK, SHORT	1
242	261713	ADJUSTMENT LOCK, POINT	1
283	107101	SOLDER LUG VITEK INCORPORATED	3

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES: XX ± 0.005
 X ± 0.010
 X ± 0.015
ANGULAR: MACHINED ± 0.1°
 BEND ± 0.5°
SURFACE: 63 /
GENERAL NOTES:
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES
MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING


NAME	DATE	SOLDER LUG VITEK INCORPORATED	
DRAWN	RH	2/11/2014	
ENG APPR	RH	-	
THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MINNETONKA, MN.			
TITLE: TM-50 OEM DUAL JAM			
MATERIAL	SIZE	DWG. NO.	REV
FINISH	B	291633	H
WEIGHT (lbs): 92.20		SHEET 7 OF 20	

D
C
B
A


8 7 6 5 4 3 2 1



INNER SEALER



DETAIL B
SMALL CYLINDER SET-UP
SCALE 1:2




DETAIL C
LARGE CYLINDER SET-UP
SCALE 1:2


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES: .XX ± 0.005
 XX ± 0.010
 X ± 0.015
ANGULAR: MACHINED ± 0.1°
 BEND ± 0.5°
SURFACE: 63
GENERAL NOTES:
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES
MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING


ITEM NO.	PART NUMBER	DESCRIPTION	QTY
38	200029	AIR CYLINDER, SMC CJPB-6-10-B	2
39	200030	SMC AIR CYLINDER, CJPB-15-10	2
45	200259	AIR FITTING 10-32 X 1/16 TB ELBOW	7
66	204056	BEARING 1/8 ID X 3/8 DIA FLANGED	4
74	209051	SPRING, STAINLESS STEEL	2
75	209244	SPRING, CUSTOM, STAINLESS STEEL	2
97	219206	DOWEL CRS .125 DIA X .50 LG.	4
98	219207	DOWEL PIN CRS 1/8 DIA X 3/4 LG	4
104	221005	SHCS SS 4-40 X .75 LG	2
126	223006	BHCS 5-40 X 3/8	4
135	223052	BHCS SS 10-32 X 3/8	4
142	230001	4-40 X 1/8 STEEL SET SCREW	4
145	230018	8-32 X 1/4 STEEL SET SCREW	6
147	230023	10-24 X 3/16 STEEL SET SCREW	5
148	230071	10-24 X 5/16 STEEL SET SCREW	5
164	244007	THERMOCOUPLE	2
165	244008	HEATER, LONG W/SWAGED-IN LEADS	2
174	250159	SEAL ROLLER, LOWER	2
201	260657	HEAT BLOCK	2
202	260666	HEAT BLOCK ISOLATOR	4
203	260669	RETAINING PIN, HEAT SHOE	2
204	261032	SLIDER SHAFT	4
205	261033	UPPER ROLLER MOUNT	2
206	261034	HEAD PLATE	2
207	261035	ANVL - INNER	1
221	261075	BUMPER, 5MM CYLINDER	2
229	261122	HEAT SHOE, ADJUSTABLE SEALER	2
244	261753	BUMPER, 5MM CYLINDER	2
282	267573	UPPER SEAL ROLLER	2

DRAWN	RH	DATE	2/11/2014
ENG APPR	RH		
TITLE:			
TM-50 OEM DUAL JAM			
MATERIAL		SIZE	DWG. NO.
FINISH		B	291633
		REV	H
		WEIGHT (lbs):	92.20
		SHEET 9 OF 20	

8 7 6 5 4 3 2 1




UNLESS OTHERWISE SPECIFIED:			NAME	DATE	<div> THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MINNETONKA, MN.</div>
DIMENSIONS ARE IN INCHES			DRAWN	RH	
TOLERANCES: .XXX ± 0.005 XX ± 0.010 X ± 0.015			ENG APPR.	RH	
ANGULAR: MACHINED ± 0.1° BEND ± 0.5°			TITLE:		TM-50 OEM DUAL JAM
SURFACE: 63			MATERIAL	SIZE	
GENERAL NOTES: - INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5 - BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED - CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED - ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN RoHS COMPLIANT PART - DO NOT SCALE DRAWING			FINISH	DWG. NO.	
				B	291633
				REV	H
			WEIGHT (lbs): 92.20		SHEET 10 OF 20



ITEM NO.	PART NUMBER	DESCRIPTION	QTY
15	104949	FS-V21R AMPLIFIER	2
16	104950	FS-V22R AMPLIFIER EXPANSION	2
17	104952	FIBER OPTIC FU-35FA	2
18	104963	F-2HA	1
19	104973	SENSOR, MOUNT	2
76	209246	SPRING, .360 DIA	1
85	217021	KNOB #8 MCMMASTER 94052A125	1
86	217022	KNOB #10, MCMMASTER 94052A131	1
88	217042	KNOB M4 RED	3
101	220048	SHCS STEEL 8-32 X 1/2	1
102	221000	SHCS SS 4-40 X 1-1/2	2
107	221025	SHCS SS 8-32 X 1/4	2
108	221026	SHCS SS 8-32 X 3/8	3
113	221039	SHCS 10-24 X 1/2	3
127	223010	BHCS SS 4-40 X 5/16	5
146	230022	10-24 X 1/4 STEEL SET SCREW	2
210	261057	GUIDE, C.T. INNER	1
211	261058	GUIDE, C.T. OUTER	1
212	261059	SHAFT, C.T. GUIDE	1
218	261069	SHAFT, C.T. GUIDE ASSEMBLY	1
219	261070	ROD, THREADED C.T. GUIDE ASSY	1
220	261071	WASHER, C.T. GUIDE ASSEMBLY	1
230	261268	MOUNT, THUMBSCREW	1
231	261269	SHAFT, EPD	1
232	261270	Mount, Inner, EPD	1
233	261271	MOUNT, OUTER EPD	1
247	262795	ADJUSTMENT KNOB - .500"	2
250	263588	C.T. GUIDE ADJUSTER	1


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES: .XXX ± 0.005
 XX ± 0.010
 X ± 0.015
ANGULAR: MACHINED ± 0.1°
 BEND ± 0.5°
SURFACE: 63
GENERAL NOTES:
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES
 MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING


NAME		DATE	
DRAWN RH		2/11/2014	
ENG APPR RH		-	
THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.			
TITLE: TM-50 OEM DUAL JAM			
MATERIAL	SIZE	DWG. NO.	REV
FINISH	B	291633	H
WEIGHT (lbs): 92.20		SHEET 11 OF 20	



ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	101078	CAPACITOR, ELEC. 1000UF 35V	1
3	103051	HOOD AMP	1
4	103057	PLUG AMP 7 PIN	1
5	103058	RECEPT AMP 4 PIN	1
7	103064	RECEPT AMP 7 PIN AMP	1
8	103127	RECEPTACLE MINI FIT JR. 2	2
9	103133	RECEPTACLE MINI FIT JR. 4	3
10	104101	TERM BLOCK MINI (SPRING)	2
11	104102	TERM GND BLOCK MINI (SPRING)	2
12	104103	TERM END CAP MINI (SPRING)	2
13	104104	TERM BRIDGE MINI (SPRING)	2
14	104106	TERM DBL BLOCK MINI (SPRING)	6
28	106043	STANDOFF 4-40 1/2"	4
29	106059	STANDOFF HEX M/F 4-40 .500" AL	2
36	150045	BOARD STEP SEAL	1
37	150050	BOARD SOLINOID FOR HEAT SHOE	1
127	223010	BHCS SS 4-40 X 5/16	5
129	223024	BHCS SS 6-32 X 1/4	13
131	223008	BHCS SS 4-40 X 1/4	12
133	223034	BHCS 8-32 X 3/8	5
169	249949	37 PIN CIRCULAR CONNECTOR	1
272	266939	DIN RAIL BPM	1

UNLESS OTHERWISE SPECIFIED:		
DIMENSIONS ARE IN INCHES		
TOLERANCES: XX ± 0.005		
XX ± 0.010		
ANGULAR: MACHINED ± 0.1°		
BEND ± 0.5°		
SURFACE: 63		
GENERAL NOTES:		
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5		
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED		
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED		
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES		
MUST RESULT IN ROHS COMPLIANT PART		
- DO NOT SCALE DRAWING		

	NAME	DATE	 THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANKATO, MN.	
DRAWN	RH	2/11/2014		
ENG APPR.	RH	-		
TITLE:				
TM-50 OEM DUAL JAM				
MATERIAL		SIZE	DWG. NO.	REV
FINISH		B	291633	H
WEIGHT (lbs): 92.20			SHEET 12 OF 20	





ITEM NO.	PART NUMBER	DESCRIPTION	QTY
2	102547	Switch MTG-206N DPDT	1
27	105705	TEMP CNTRLR 12 VDC OUT	2
43	200253	10-32 x 1/16 HOSE BARB	2
47	200261	AIR FIR 10-32 TEE TO 1/16" TB	1
48	200267	AIR FIT 1/8NPT FEMALE X 1/8TB	1
51	200401	AIR REGULATOR SMC ARJ210-M5	1
60	200801	GUAGE PRESSURE GP-100	1
88	217042	KNOB M4 RED	3
108	221026	SHCS SS 8-32 X 3/8	3
121	221070	SHCS SS 5/16-18 X 1/2	2
122	221071	SHCS SS 5/16-18 X 3/4	2
129	223024	BHCS SS 6-32 X 1/4	13
132	223033	BHCS SS 8-32 X 1/4	3
133	223034	BHCS 8-32 X 3/8	5
139	223083	BHCS SS 5/16 X 1/2	2
182	254578	CONTROLLER PLATE RISER	2
183	254579	CONTROLLER ARM	1
194	256971	CONTROLLER PLATE	1
214	261062	COVER, SEALER INNER	1
215	261063	COVER, SEALER OUTER	1
242	261709	PANEL, FRONT-BASE MACHINE	1
245	262134	COVER, SEALER LOWER	1
248	263063	SEAL LOCK, SPROCKET SIDE	1

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES: .XX ± 0.005
 XX ± 0.010
 X ± 0.015
ANGULAR: MACHINED ± 0.1°
 BEND ± 0.5°
SURFACE: 63
GENERAL NOTES:
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES
MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING

NAME	DATE		
DRAWN RH	2/11/2014		
ENG APPR RH	-		
TITLE: TM-50 OEM DUAL JAM			
MATERIAL	SIZE	DWG. NO.	REV
FINISH	B	291633	H
WEIGHT (lbs): 92.20		SHEET 13 OF 20	

V-TEK
INCORPORATED
THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT
MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS
PERMISSION OF V-TEK INC., MANIKATO, MN.





ITEM NO.	PART NUMBER	DESCRIPTION	QTY
6	103063	PLUG AMP 7 PIN	1
24	105573	GEAR HEAD 50:1 OGN50KAV-TEK	1
26	105695	TAKUP MOTOR 0IK1GN-AW3-E1 ROHS	1
90	219003	1/8 X 3/4 LG. SS DOWEL PIN	1
106	221016	SHCS SS 6-32 x 5/8	2
119	221063	SHCS SS 1/4-20 X 3/4	18
125	221720	SHCS SS M3 X 40	4
146	230022	10-24 X 1/4 STEEL SET SCREW	2
154	236061	SLOTTED M2 X 16	2
159	238042	M3 SS FLAT WASHER	4
161	238082	M3 ZINC SPLIT LOCK WASHER	4
166	246510	CONDUIT FITTING, 90 DEG	1
167	246511	CONDUIT HOUSING, SIZE 11	1
168	246512		1
176	253780	TAKE UP REEL SPINDLE, 72MM	1
184	255339	TAKE-UP MOTOR ELECTRICAL CAP	1
185	255340	TAKE-UP MOTOR ELECT. CAP END	1
195	257999	REEL SPINDLE KEY, 72MM	1
223	261088	TAKE UP MOTOR MOUNT	1
224	261089	REEL EXTENSION ADAPTER	2

UNLESS OTHERWISE SPECIFIED:

DIMENSIONS ARE IN INCHES

TOLERANCES: JXX \pm 0.005

XX \pm 0.010

X \pm 0.015

ANGULAR: MACHINED \pm 0.1°

BEND \pm 0.5°

SURFACE: 63

GENERAL NOTES:

- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 \pm .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING

NAME	DATE
DRAWN RH	2/11/2014
ENG APPR. RH	-

TITLE:


TM-50 OEM DUAL JAM

MATERIAL	SIZE	DWG. NO.	REV
FINISH	B	291633	H

WEIGHT (lbs): 92.20	SHEET 15 OF 20
---------------------	----------------


V-TEK
INCORPORATED


THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MINNETONKA, MN.




ITEM NO.	PART NUMBER	DESCRIPTION	QTY
68	205016	BUSHING, FLANGED .5 ID, .75 OD, .5 L	1
81	216504	QUIKLOC SHAFT COLLAR	1
119	221063	SHCS SS 1/4-20 X 3/4	18
137	223060	BHCS 1/4-20 X 1/2	3
155	238001	1/4 SS FLAT WASHER	3
175	250214	REEL SUPPORT SHAFT	1
181	254566	FEED REAL ARM	1
222	261087	22" REEL SPACER	1
224	261089	REEL EXTENSION ADAPTER	2
225	261091	22" REEL SPACER	1

UNLESS OTHERWISE SPECIFIED:			
DIMENSIONS ARE IN INCHES			
TOLERANCES: .XXX ± 0.005			
XX ± 0.010			
X ± 0.015			
ANGULAR: MACHINED ± 0.1°			
BEND ± 0.5°			
SURFACE: 63			
GENERAL NOTES:			
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5			
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED			
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED			
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES			
MUST RESULT IN ROHS COMPLIANT PART			
- DO NOT SCALE DRAWING			
DRAWN	RH	NAME	DATE
ENG APPR	RH		2/11/2014
THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.			
TITLE:			
TM-50 OEM DUAL JAM			
MATERIAL	SIZE	DWG. NO.	REV
	B	291633	H
FINISH	WEIGHT (lbs): 92.20		SHEET 16 OF 20



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
33	111004	SAFETY STICKER EX. POINT	1
41	200214	AIR FIT 1/4 NPT M X 10-32 F	1
43	200254	AIR FIT 1/8 BARB X 10-32MALE	1
48	200281	AIR FITTING, 1/4" MALE COUPLER	1
49	200296	AIR FITTING 1/8 PLUG	2
51	200421	REGULATOR AND FILTER WILKERSON	1
52	200445	BRACKET AIR REGULATOR	1
53	200447	AIR REGULATOR PANEL NUT	1
60	200851	GUAGE AIR PRESSURE 0-160	1
82	217007	KNOB, 1/2-13 FOUR LOBE	2
128	223024	BHCS SS 6-32 X 1/4	13
133	223043	BHCS SS 10-24 X 1/4	3
208	261056	PANEL, REAR BASE	1
208	107101	SOLDER LUG 	3

UNLESS OTHERWISE SPECIFIED:		NAME	DATE
DIMENSIONS ARE IN INCHES		RH	2/11/2014
TOLERANCES: XX ± 0.005		THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.	
XX ± 0.010			
ANGULAR: MACHINED ± 0.1°			
BEND ± 0.5°			
SURFACE: 63			
GENERAL NOTES:			
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5			
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED			
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED			
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART			
- DO NOT SCALE DRAWING			
TITLE:		TM-50 OEM DUAL JAM	
MATERIAL:		SIZE	DWG. NO.
FINISH:		B	291633
		REV	H
		WEIGHT (lbs): 92.20	
		SHEET 17 OF 20	



ITEM NO.	PART NUMBER	DESCRIPTION	QTY
100	220035	SHCS STEEL 6-32 X 1/2	2
143	230011	6-32 X 1/8 STEEL SET SCREW	1
187	256221	SENSOR ROD HOOK	1
189	256223	SENSOR ROD	1
283	291645	CONTROLLER, BPM OEM 2 SENSOR	1

UNLESS OTHERWISE SPECIFIED:			NAME	DATE
DIMENSIONS ARE IN INCHES			DRAWN	RH
TOLERANCES: .XXX ± 0.005			ENG APPR.	RH
XX ± 0.010			2/11/2014	
X ± 0.015				
ANGULAR: MACHINED ± 0.1°				
BEND ± 0.5°				
SURFACE: 63				
GENERAL NOTES:				
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5				
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED				
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED				
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES				
MUST RESULT IN ROHS COMPLIANT PART				
- DO NOT SCALE DRAWING				
			V-TEK INCORPORATED	
			THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.	
TITLE:			TM-50 OEM DUAL JAM	
MATERIAL	SIZE	DWG. NO.	REV	
FINISH	B	291633	H	
			WEIGHT (lbs): 92.20	SHEET 18 OF 20


8 7 6 5 4 3 2 1

D

C

B

A





AIR LINE LENGTHS

200304 - TWIN HOSE (CLEAR/BLACK)
5-1/2" - INSIDE SEALER TWIN HOSE
11" - OUTSIDE SEALER TWIN HOSE
2-3/4" - AIR FLOW CONTROL VALVE
1" - FLOW CONTROL VALVE TO BRASS TIE
200301 - 6-1/2" - AIR SUPPLY LINE (LARGE BLUE HOSE)
- NOT SHOWN IN PNEUMATIC DIAGRAM
200302 - 13" - AIR SUPPLY TO AIR VALVE (SMALL BLUE LINE)
200302 - 5-1/2" - AIR REGULATOR TO GAUGE (SMALL BLUE LINE)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	P200401	AIR REGULATOR SMC ARJ210-M5	1
2	P200801	GAUGE PRESSURE	1
3	P200603	AIR VALVE MB3E1 1-24 VDC	2
4	P200692	AIR FLOW CONTROL	2
5	P200029	AIR CYLINDER, SMC CJPB-6-10-B	2
6	P200030	AIR CYLINDER SMC, CJPB-15-10-H4	2
7	P200691	AIR VALVE FLOW CNTRL, MUFFLER	2
8	P200255	AIR FIT BARB TEE 1/16 TB	2


UNLESS OTHERWISE SPECIFIED:			
DIMENSIONS ARE IN INCHES			
TOLERANCES: .XXK ± 0.005			
X ± 0.010			
ANGULAR: MACHINED ± 0.1°			
SURFACE: 63			
GENERAL NOTES:			
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5			
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED			
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED			
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART			
- DO NOT SCALE DRAWING			
DRAWN		NAME	DATE
ENG APPR		RH	4/1/14
THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MINNETONKA, MN.			
TITLE:			
TM50 PNEUMATIC DIAGRAM			
MATERIAL		SIZE	DWG. NO.
FINISH		B	291633
		REV	H
		WEIGHT (lbs): 0.00	SHEET 19 OF 20






NOTE:
CHECK TO ENSURE THAT THE CONNECTION
POINT FOR THE GROUNDING STRAP IS FREE OF
PAINT OR OTHER MATERIALS TO ENSURE A
GOOD GROUND CONNECTION. REMOVE PAINT
OR MATERIAL AS NEEDED WITH A GRINDER.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
29	109091	MEMBRANE SWITCH PAD, TM50, ESD	1
37	217208	FEET RUBBER	4
53	261073	TM50 ENCLOSURE, LOWER HALF	1


UNLESS OTHERWISE SPECIFIED:			NAME		DATE		
DIMENSIONS ARE IN INCHES			DRAWN	RH	10/18/13	THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANKATO, MN.	
TOLERANCES: .XXX ± 0.005			ENG APPR.		-		
.XX ± 0.010 X ± 0.015							
ANGULAR: MACHINED ± 0.1° BEND ± 0.5°			TITLE: CONTROLLER, BPM OEM 2 SENSOR				
SURFACE: 63							
GENERAL NOTES: - INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5 - BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED - CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED - ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART - DO NOT SCALE DRAWING			MATERIAL		SIZE DWG. NO.	REV	
			FINISH		B	291645	H
					WEIGHT (lbs):		SHEET 2 OF 6



NOTE:
SEE WIRING DIAGRAM FOR TYPE
AND PLACEMENT OF SOCKET PINS.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	03977	#4 STAINLESS WASHER	2
4	102035	LCD DISPLAY 4X20 BACKLIT ESD	1
5	102275	PIC12C671	1
14	103127	RECEPTACLE MINI FIT JR. 2	5
15	103129	RECEPTACLE MINI FIT JR. 6	1
16	103131	RECEPTACLE MINI FIT JR.	37
17	103133	RECEPTACLE MINI FIT JR. 4	5
18	103135	RECEPTACLE MINI FIT JR. 8	1
26	106048	STAND OFF CLEAR .38 LG #4-40	5
27	106049	STAND OFF CLEAR .50 LG #4-40	5
32	150027	TENSION CONTROL BOARD , NEW	1
34	150048	CIRCUIT BRD. COMP. TM50XL	1
38	221005	SHCS SS 4-40 X .75 LG	5
47	239051	4-40 NYLOK NUT	13
54	266651	TAKE-UP BOARD BRACE	1

UNLESS OTHERWISE SPECIFIED:		NAME		DATE	
DIMENSIONS ARE IN INCHES		DRAWN		RH	
TOLERANCES: .XX ± 0.005		10/18/13			
XX ± 0.010					
X ± 0.015					
ANGULAR: MACHINED ± 0.1°					
BEND ± 0.5°					
SURFACE: 63					
GENERAL NOTES:					
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5					
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED					
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED					
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES					
MUST RESULT IN ROHS COMPLIANT PART					
- DO NOT SCALE DRAWING					
		TITLE:			
		MATERIAL:			
		FINISH:			
		SIZE		DWG. NO.	
		B		291645	
		WEIGHT (lbs):		REV	
				H	
				SHEET 3 OF 6	



NOTE:
SEE WIRING DIAGRAM FOR TYPE
AND PLACEMENT OF SOCKET PINS.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
2	101908	FILTER AC ENTRY FUSED	1
3	102013	DIODE 4001	1
7	102624	DIN RECEPT	1
8	103012	D SUB MOUNTING HEX POST (2)	4
9	103013	SUB D MALE 9 PIN	1
10	103014	SUB D FEMALE 9 PIN	1
11	103031	RECEPT AMP 9 PIN	1
12	103044	PIN AMP (F) (18AWG)	11
13	103045	PIN AMP (F) (22 AWG)	5
14	103127	RECEPTACLE MINI FIT JR. 2	5
16	103131	RECEPTACLE MINI FIT JR	37
17	103133	RECEPTACLE MINI FIT JR. 4	5
19	103165	RECEPT 19 PIN REV AMP	1
21	104101	TERM BLOCK MINI (SPRING)	1
22	104102	TERM GND BLOCK MINI (SPRING)	3
23	104103	TERM END CAP MINI (SPRING)	2
24	104106	TERM DBL BLOCK MINI (SPRING)	5
28	106105	STAND OFF WHITE .50 LG #6-32	4
33	150032	AUTO SELECT BOARD, AC115/23	1
39	221012	SHCS SS 6-32 X 1/4	4
40	223010	BHCS SS 4-40 X 5/16	8
41	223025	BHCS SS 6-32 X 3/8	4
42	223033	BHCS SS 8-32 X 1/4	2
47	239051	4-40 NYLOK NUT	13
48	239052	#8-32 LOCK NUT	4
50	253072	"DIN RAIL BRACKET"	1

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
TOLERANCES: .XX ± 0.005
 X ± 0.010
 X ± 0.015
ANGULAR: MACHINED ± 0.1°
 BEND ± 0.5°
SURFACE: 63


GENERAL NOTES:
- INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5
- BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED
- CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED
- ALL MATERIALS, COATINGS, & CLEANING PROCESSES
MUST RESULT IN ROHS COMPLIANT PART
- DO NOT SCALE DRAWING

NAME	DATE
DRAWN RH	10/18/13
ENG APPR	-

TITLE:
CONTROLLER, BPM OEM 2 SENSOR


MATERIAL	SIZE	DWG. NO.	REV
FINISH	B	291645	H
WEIGHT (lbs):			SHEET 4 OF 6

THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.



ITEM NO.	PART NUMBER	DESCRIPTION	QTY
6	102607	E-STOP	1
20	103499	TRANSFORMER	1
25	104160	TERM END CAP	1
29	109091	MEMBRANE SWITCH PAD, TM50, ESD	1
30	111004	SAFETY STICKER EX. POINT	1
31	111005	SAFETY STICKER SETUP MANUAL	1
35	157029	POWER SUPPLY 24 DC 4.2A	1
36	217044	KNOB BLACK	1
43	223034	BHCS 8-32 X 3/8	1
44	223050	BHCS SS 10-32 X 1/4	2
45	236020	PHMS #8-32 X 3/8	6
46	239004	10-24 SS HEX NUT	4
49	239053	#8-32 LOCK NUT	1
51	257476	TM220-330 Controller DIN Rail (Bottom)	1
52	257744	ENCLOSURE UPPER HALF	1

UNLESS OTHERWISE SPECIFIED:		NAME		DATE	
DIMENSIONS ARE IN INCHES		DRAWN		RH 10/18/13	
TOLERANCES: .XXX ± 0.005		ENG APPR.		 THE INFORMATION IN THIS DOCUMENT IS PROPRIETARY AND CONFIDENTIAL. IT MAY NOT BE REPRODUCED, TRANSMITTED, OR USED WITHOUT THE EXPRESS PERMISSION OF V-TEK INC., MANIKATO, MN.	
.XX ± 0.010					
X ± 0.015					
ANGULAR: MACHINED ± 0.1°					
BEND ± 0.5°		TITLE: CONTROLLER, BPM OEM 2 SENSOR			
SURFACE: 63					
GENERAL NOTES: - INTERPRET GEOMETRIC TOLERANCING PER ANSI Y14.5 - BREAK ALL SHARP EDGES .010 MAX UNLESS NOTED - CHAMFER ALL HOLES .015 X .015 ± .010 UNLESS NOTED - ALL MATERIALS, COATINGS, & CLEANING PROCESSES MUST RESULT IN ROHS COMPLIANT PART - DO NOT SCALE DRAWING					
MATERIAL		SIZE		DWG. NO.	
FINISH		B		291645	
				REV	
				H	
WEIGHT (lbs):				SHEET 5 OF 6	

	<p>751 Summit Avenue Mankato, MN USA 56001</p> <p>Website: www.vtekusa.com Email: service@vtekusa.com Phone: (507) 387-2039</p>
---	--

For inquiries regarding spare parts, tape and reel supplies, or the service department, please call or write:

Phone: (507) 387-2039

Email: service@vtekusa.com

Please provide the machine model and serial numbers with all inquiries.

NOTES

OEM TM-50 with Dual Jam Sensors

Document List

Section	Description	File Name
Front	Page 1 of 1	D292414.1d.fm
EC Declaration of Conformity	Page 1 of 1	TM-50 DOC.doc
Preface	Pages i-vi	61685113.fm
Table of Contents	Page 1 of 1	D291640.8a.fm
Chapter 1: Getting Started	Pages 1-12	D291640.5e.fm
Chapter 2: Controller	Pages 13-28	D291640.1b.fm
Chapter 3: Setup and Operation	Pages 29-46	D291640.6c.fm
Chapter 4: Maintenance	Pages 47-56	D291640.2a.fm
Exploded View Dual Jam Taper	Page 57-74	291633.slddrw
Exploded View BP Controller	Page 75-79	291645.slddrw
Appendix A: Sensors	Pages A-1 to A-2	61004016.fm
Appendix B: Temp. Controllers	Pages B1 to B-4	61574415.fm
Spare Parts List	Pages 1 of 1	D291368.1e.fm
Spare Parts List - Sensors	Page 1 of 1	D291640.10a.fm
Service and Parts Contact	Page 1 of 1	61053915.fm
	This document	D292414.8c.fm
Warranty Document	Page 1 of 1	WI201.16 Rev. 3
Back	Page 1 of 1	61666111.fm



MINNESOTA • MEXICO

751 Summit Avenue / P.O. Box 3104
Mankato, Minnesota 56002, USA
Telephone: (507) 387-2039
Fax No. (507) 387-2257
I.S.O. 9001:2008 Certified

EXPRESS WARRANTY, EXCLUSION AND DISCLAIMER OF UNSTATED WARRANTIES AND LIMITATION OF LIABILITY

1. V-TEK, Inc (V-TEK) warrants for one year from date of receipt by end user that equipment manufactured by V-TEK will be free of defects in workmanship and materials.
2. All integrated products purchased by V-TEK and integrated on to V-TEK equipment shall be covered in accordance with the manufacturer's pass through warranty and limited in costs equal to the amount of the manufacturer's pass through warranty.
3. V-TEK's obligation under this warranty applies only to the original Customer and commences when V-TEK is notified of name, address of Customer, and date of receipt of equipment.
4. During the warranty period, V-TEK will replace any defective nonconsumable parts returned for that purpose to the designated V-TEK Replacement Parts Center or at V-TEK's option, refund original cost of equipment.
5. Authorization to return Articles purchased from V-TEK must be obtained by Customer before return shipping commences.
6. Credit may be granted, less an appropriate restocking charge of 15 to 20% of invoice amount, depending on the reason for the return and condition of the Articles.
7. Returns should always be carefully packed in original shipping carton and sent via ground service. V-TEK does not assume any liability for damage incurred during shipment.
8. For the first 30 days that you own your V-TEK product, V-TEK will be responsible for ground shipments to and from V-TEK's facility in Mankato, MN, U.S.A. or its designate. For the remainder of your warranty V-TEK will pay freight for returning your product to you after its repair.
9. Customer shall bear all charges for customs duty fees or freight above the ground rate or for articles returned which are not defective.
10. Collect shipments will not be accepted.
11. Insurance coverage during shipping is the responsibility of the Customer. V-TEK does not assume any liability for damage incurred during shipment.
12. The warranty applies only to normal use of the equipment and shall be void if V-TEK determines that defects in or failures of the equipment were caused by the Customer's negligence including the lack of proper preventative maintenance, misuse or accident or by unauthorized repair, alteration or installation.
13. This Warranty does not extend to consumable items or mechanical parts subject to normal wear.
14. Customer's exclusive remedy for claims against V-TEK shall be the repair or replacement of defective equipment and parts.
15. Any modification to the standard configuration of this equipment as delivered will void the warranty, unless V-TEK personnel make the modification.

THIS WARRANTY IS EXPRESSLY MADE IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL V-TEK BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL PENALTIES OR DAMAGES, INCLUDING LOST PROFITS OR PENALTIES AND/OR DAMAGES FOR DELAY IN DELIVERY OR FAILURE TO GIVE NOTICE OF DELAY EVEN IF V-TEK HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

PASS THROUGH WARRANTIES ARE AVAILABLE FROM THE RESPECTIVE MANUFACTURERS.

SERIAL NUMBER _____

WI201.16 Rev. 4
05/13/2014

Tell us how we are doing. Please take this opportunity to fill out our short survey on our website, so V-TEK can continue to be a leader in customer service. Please go to the direct link <http://tinyurl.com/3vs4day> or go to our website www.vtekusa.com under Contact Us and locate the Equipment and Service Customer Survey. Thank you for your feedback and support.



**751 Summit Avenue
Mankato, MN 56001**

(507) 387-2039 FAX: (507) 387-2257

**www.vtekusa.com
Email: info@vtekusa.com**